


USER MANUAL



VOSS

CONTENTS

| | |
|-----------------------------------|----|
| 1. SAFETY INFORMATION..... | 3 |
| 2. SAFETY INSTRUCTIONS..... | 5 |
| 3. INSTALLATION..... | 8 |
| 4. PRODUCT DESCRIPTION..... | 9 |
| 5. BEFORE FIRST USE..... | 10 |
| 6. HOB - DAILY USE..... | 11 |
| 7. HOB - HINTS AND TIPS..... | 11 |
| 8. HOB - CARE AND CLEANING..... | 13 |
| 9. OVEN - DAILY USE..... | 13 |
| 10. OVEN - HINTS AND TIPS..... | 15 |
| 11. OVEN - CARE AND CLEANING..... | 28 |
| 12. TROUBLESHOOTING..... | 31 |
| 13. ENERGY EFFICIENCY..... | 32 |
| 14. ENVIRONMENTAL CONCERNS..... | 33 |

DEAR CUSTOMER

Thank you for choosing this Voss-Electrolux product. We have created it to give you impeccable performance for many years, with innovative technologies that help make life simpler – features you might not find on ordinary appliances. Please spend a few minutes reading to get the very best from it.

Visit our website to:



Get usage advice, brochures, trouble shooter, service and repair information:
www.voss.dk



Register your product for better service:
www.voss.dk

CUSTOMER CARE AND SERVICE

Always use original spare parts.

When contacting our Authorised Service Centre, ensure that you have the following data available: Model, PNC, Serial Number.

The information can be found on the rating plate.

 Warning / Caution-Safety information

 General information and tips

 Environmental information

Subject to change without notice.

1. SAFETY INFORMATION

Before the installation and use of the appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

1.1 Children and vulnerable people safety

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved. Children of less than 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.
- **WARNING:** The appliance and its accessible parts become hot during use. Keep children and pets away from the appliance when in use and when cooling down.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

1.2 General Safety

- This appliance is for cooking purposes only.
- This appliance is designed for single household domestic use in an indoor environment.
- This appliance may be used in, offices, hotel guest rooms, bed & breakfast guest rooms, farm guest

houses and other similar accommodation where such use does not exceed (average) domestic usage levels.

- Only a qualified person must install this appliance and replace the cable.
- This appliance must be connected to the mains with a H05VV-F type cable to withstand the temperature of the rear panel.
- This appliance is intended for use up to an altitude of 2000 m above sea level.
- This appliance is not intended to be used on ships, boats or vessels.
- Do not install the appliance behind a decorative door in order to avoid overheating.
- Do not install the appliance on a platform.
- Do not operate the appliance by means of an external timer or separate remote-control system.
- **WARNING:** Unattended cooking on a hob with fat or oil can be dangerous and may result in fire.
- Never use water to extinguish the cooking fire. Switch off the appliance and cover flames with e.g. a fire blanket or lid.
- **CAUTION:** The cooking process has to be supervised. A short term cooking process has to be supervised continuously.
- **WARNING:** Danger of fire: Do not store items on the cooking surfaces.
- Do not use a steam cleaner to clean the appliance.
- Do not use harsh abrasive cleaners or sharp metal scrapers to clean the glass door or the glass of hinged lids of the hob since they can scratch the surface, which may result in shattering of the glass.
- Metallic objects such as knives, forks, spoons and lids should not be placed on the hob surface since they can get hot.
- If the glass ceramic surface / glass surface is cracked, switch off the appliance and unplug it from the mains. In case the appliance is connected to the mains directly using junction box, remove the fuse to

disconnect the appliance from power supply. In either case contact the Authorised Service Centre.

- **WARNING:** The appliance and its accessible parts become hot during use. Care should be taken to avoid touching heating elements.
- Always use oven gloves to remove or insert accessories or ovenware.
- Before maintenance, cut the power supply.
- **WARNING:** Ensure that the appliance is switched off before replacing the lamp to avoid the possibility of electric shock.
- If the mains power supply cable is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- Be careful when you touch the storage drawer. It can get hot.
- To remove the shelf supports first pull the front of the shelf support and then the rear end away from the side walls. Install the shelf supports in the opposite sequence.
- The means for disconnection must be incorporated in the fixed wiring in accordance with the wiring rules.
- **WARNING:** Use only hob guards designed by the manufacturer of the cooking appliance or indicated by the manufacturer of the appliance in the instructions for use as suitable or hob guards incorporated in the appliance. The use of inappropriate guards can cause accidents.

2. SAFETY INSTRUCTIONS

2.1 Installation



WARNING!

Only a qualified person must install this appliance.

- Remove all the packaging.
- Do not install or use a damaged appliance.
- Follow the installation instructions supplied with the appliance.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not pull the appliance by the handle.
- The kitchen cabinet and the recess must have suitable dimensions.

- Keep the minimum distance from other appliances and units.
- Install the appliance in a safe and suitable place that meets installation requirements.
- Parts of the appliance carry current. Close the appliance with furniture to prevent touching the dangerous parts.
- The sides of the appliance must stay next to appliances or units with the same height.
- Do not install the appliance adjacent to a door or under a window. This prevents hot cookware to fall from the appliance when the door or the window is opened.
- Make sure to install a stabilizing means in order to prevent tipping of the appliance. Refer to Installation chapter.

2.2 Electrical Connection



WARNING!

Risk of fire and electric shock.

- All electrical connections should be made by a qualified electrician.
- The appliance must be earthed.
- Make sure that the parameters on the rating plate are compatible with the electrical ratings of the mains power supply.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Do not let mains cables touch or come near the appliance door or the niche below the appliance, especially when it operates or the door is hot.
- The shock protection of live and insulated parts must be fastened in such a way that it cannot be removed without tools.
- Connect the mains plug to the mains socket only at the end of the installation. Make sure that there is access to the mains plug after the installation.
- If the mains socket is loose, do not connect the mains plug.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.

- Use only correct isolation devices: line protecting cut-outs, fuses (screw type fuses removed from the holder), earth leakage trips and contactors.
- The electrical installation must have an isolation device which lets you disconnect the appliance from the mains at all poles. The isolation device must have a contact opening width of minimum 3 mm.
- Fully close the appliance door before you connect the mains plug to the mains socket.

2.3 Use



WARNING!

Risk of injury and burns.
Risk of electrical shock.

- Do not change the specification of this appliance.
- Make sure that the ventilation openings are not blocked.
- Do not let the appliance stay unattended during operation.
- Deactivate the appliance after each use.
- Be careful when you open the appliance door while the appliance is in operation. Hot air can release.
- Do not operate the appliance with wet hands or when it has contact with water.
- Do not use the appliance as a work surface or as a storage surface.
- Do not use aluminum foil or other materials between the cooking surface and the cookware, unless otherwise specified by the manufacturer of this appliance.
- Use only accessories recommended for this appliance by the manufacturer.
- Always use glass and jars approved for preserving purposes.



WARNING!

Risk of fire and explosion.

- Fats and oil when heated can release flammable vapours. Keep flames or heated objects away from fats and oils when you cook with them.
- The vapours that very hot oil releases can cause spontaneous combustion.

- Used oil, that can contain food remnants, can cause fire at a lower temperature than oil used for the first time.
- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- Do not let sparks or open flames to come in contact with the appliance when you open the door.
- Open the appliance door carefully. The use of ingredients with alcohol can cause a mixture of alcohol and air.



WARNING!

Risk of damage to the appliance.

- To prevent damage or discoloration to the enamel:
 - do not put ovenware or other objects in the appliance directly on the bottom.
 - do not put aluminium foil directly on the bottom of cavity.
 - do not put water directly into the hot appliance.
 - do not keep moist dishes and food in the appliance after you finish the cooking.
 - be careful when you remove or install the accessories.
- Discoloration of the enamel or stainless steel has no effect on the performance of the appliance.
- Use a deep pan for moist cakes. Fruit juices cause stains that can be permanent.
- Do not keep hot cookware on the control panel.
- Do not let cookware boil dry.
- Be careful not to let objects or cookware fall on the appliance. The surface can be damaged.
- Do not activate the cooking zones with empty cookware or without cookware.
- Cookware made of cast iron, aluminium or with a damaged bottom can cause scratches. Always lift these objects up when you have to move them on the cooking surface.

2.4 Care and Cleaning



WARNING!

Risk of injury, fire, or damage to the appliance.

- Before maintenance, deactivate the appliance. Disconnect the mains plug from the mains socket.
- Make sure the appliance is cold. There is the risk that the glass panels can break.
- Replace immediately the door glass panels when they are damaged. Contact the Authorised Service Centre.
- Be careful when you remove the door from the appliance. The door is heavy!
- Fat and food remaining in the appliance can cause fire.
- Clean regularly the appliance to prevent the deterioration of the surface material.
- Make sure the cavity and the door are wiped dry after each use. Steam produced during the operation of the appliance condensates on cavity walls and can cause corrosion. To decrease the condensation operate the appliance for 10 minutes before cooking.
- Clean the appliance with a moist soft cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- If you use an oven spray, follow the safety instructions on the packaging.
- Do not clean the catalytic enamel (if applicable) with any kind of detergent.

2.5 Internal lighting



WARNING!

Risk of electric shock.

- Concerning the lamp(s) inside this product and spare part lamps sold separately: These lamps are intended to withstand extreme physical conditions in household appliances, such as temperature, vibration, humidity, or are intended to signal information about the operational

status of the appliance. They are not intended to be used in other applications and are not suitable for household room illumination.

- This product contains a light source of energy efficiency class G.
- Use only lamps with the same specifications.

2.6 Service

- To repair the appliance contact the Authorised Service Centre.
- Use original spare parts only.

3. INSTALLATION



WARNING!
Refer to Safety chapters.

3.1 Technical data

| Dimensions | |
|------------|--------------|
| Height | 850 - 936 mm |
| Width | 596 mm |
| Depth | 600 mm |

3.2 Electrical installation



WARNING!
The manufacturer is not responsible if you do not follow the safety precautions from Safety chapters.

This appliance is supplied without a main plug or a main cable.

Applicable types of cables for different phases:

| Phase | Min. size cable |
|----------------|-----------------------|
| 1 | 3x6.0 mm ² |
| 3 with neutral | 5x1.5 mm ² |




WARNING!
The power cable must not touch the part of the appliance shaded in the illustration.

2.7 Disposal



WARNING!
Risk of injury or suffocation.

- Contact your municipal authority for information on how to dispose of the appliance.
- Disconnect the appliance from the mains supply.
- Cut off the mains electrical cable close to the appliance and dispose of it.



3.3 Anti-tilt protection



CAUTION!
Install the anti-tilt protection to prevent the appliance from falling under incorrect loads. The anti-tilt protection only works when the appliance is put in a correct area.

Your appliance has the symbols shown on the pictures (if applicable) to remind you about the installation of the anti-tilt protection.






Make sure you install the anti-tilt protection at the correct height.

For more information about the installation of the appliance refer to a separate installation booklet


4. PRODUCT DESCRIPTION

4.1 General overview



- 1** Knob for the heating functions
- 2** Control knob (for the temperature)
- 3** Temperature indicator / symbol
- 4** Knobs for the hob
- 5** Heating element
- 6** Lamp
- 7** Shelf support, removable
- 8** Fan
- 9** Shelf positions
- 10** Cavity embossment - Aqua cleaning container

4.2 Hob overview



- 1** Cooking zone
- 2** Residual Heat Indicator

4.3 Accessories

- **Wire shelf**
For cookware, cake tins, roasts.

- **Baking tray**
For cakes and biscuits.
- **Grill- / Roasting pan**

To bake and roast or as pan to collect fat.

- **Storage drawer**

The storage drawer is below the oven cavity.

5. BEFORE FIRST USE



WARNING!
Refer to Safety chapters.

5.1 Initial Cleaning

Remove all accessories and removable shelf supports from the oven.



Refer to "Care and cleaning" chapter.

Clean the oven and the accessories before the first use.

Put the accessories and the removable shelf supports back to their initial position.

5.2 Preheating

Preheat the empty oven before first use.


1. Set the function Set the maximum temperature.
2. Let the oven operate for 1 hour.
3. Set the function Set the maximum temperature.
4. Let the oven operate for 15 minutes.
5. Set the function Set the maximum temperature.
6. Let the oven operate for 15 minutes.
7. Turn off the oven and let it cool down.

Accessories can become hotter than usual. The oven can emit an odour and smoke. Make sure that the airflow in the room is sufficient.

5.3 Opening and closing the door with the mechanical door lock

The mechanical door lock is activated by default.


To open the door move the lock to the right.




Close the door without pressing the lever.

5.4 Deactivating the mechanical door lock - in the main oven


1. Press the door trim B at each side. The seal releases.



2. Pull the door trim up and remove it.
3. Remove the lever 1, move it to the right 2 and put it back in.



4. Hold the door trim B at each side and position it on the inner edge of the door. Put the door trim into the top edge of the door.



Activating the mechanical door lock

Do the above procedure again and move the lever back to the left.

- i** Deactivating the appliance does not deactivate the mechanical door lock.

6. HOB - DAILY USE

! **WARNING!**
Refer to Safety chapters.

6.1 Heat setting

| Symbols | Function |
|---------|---------------|
| 0 | Off position |
| | Keep warm |
| 1 - 9 | Heat settings |

- Use the residual heat to decrease energy consumption. Deactivate the cooking zone approximately 5 - 10 minutes before the cooking process is completed.

Turn the knob for the selected cooking zone to a necessary heat setting.

7. HOB - HINTS AND TIPS

! **WARNING!**
Refer to Safety chapters.

7.1 Cookware

The cooking results depend on the cookware material

To complete the cooking process, turn the knob to the off position.

6.2 Residual heat indicator

- !** **WARNING!**
As long as the indicator is visible, there is a risk of burns from residual heat.

The indicator appears when a cooking zone is hot, but it does not function if mains power is disconnected.

The indicator may also appear:

- for the neighbouring cooking zones even if you are not using them,
- when hot cookware is placed on cold cooking zone,
- when the hob is deactivated but the cooking zone is still hot.


The indicator disappears when the cooking zone has cooled down.

- i** The bottom of the cookware must be as thick and flat as possible. Ensure pan bases are clean and dry before placing on the hob surface.

i Do not use cookware on the ceramic hob with bases with pronounced edges or ridges, e.g. cast iron pans. These could scratch or scour the hob surface permanently.

i Cookware made of enamelled steel and with aluminium or copper bottoms can cause a colour change on the glass-ceramic surface.

To save energy and ensure that the hob operates properly the cookware bottom must have a suitable minimum diameter.



7.2 Minimum cookware diameter

| Cooking zone | Cookware diameter (mm) | Power (W) |
|--------------|------------------------|-----------|
| Left rear | 125 - 145 | 1200 |
| Right rear | 150 - 180 | 1800 |
| Right front | 125 - 145 | 1200 |
| Left front | 180 - 210 | 2300 |

7.3 Simplified cooking guide

i The data in the table is for guidance only.

| Heat setting | Use to: | Time (min) | Hints |
|---|--|--------------|--|
|  - 1 | Keep cooked food warm. | as necessary | Put a lid on the cookware. |
| 1 - 2 | Hollandaise sauce; melt: butter, chocolate, gelatine. | 5 - 25 | Mix from time to time. |
| 2 | Solidify: fluffy omelettes, baked eggs. | 10 - 40 | Cook with a lid on. |
| 2 - 3 | Simmer rice and milk-based dishes, heat up ready-cooked meals. | 25 - 50 | Add at least twice as much liquid as rice, mix milk dishes halfway through the procedure. |
| 3 - 4 | Stew vegetables, fish, meat. | 20 - 45 | Add a few tablespoons of water. Check the water amount during the process. |
| 4 - 5 | Steam potatoes and other vegetables. | 20 - 60 | Cover the bottom of the pot with 1-2 cm of water. Check the water level during the process. Keep the lid on the pot. |

| Heat setting | Use to: | Time (min) | Hints |
|--------------|--|--------------|---------------------------------------|
| 4 - 5 | Cook larger quantities of food, stews and soups. | 60 - 150 | Up to 3 l of liquid plus ingredients. |
| 6 - 7 | Gentle fry: escalope, veal cordon bleu, cutlets, rissoles, sausages, liver, roux, eggs, pancakes, doughnuts. | as necessary | Turn over when needed. |
| 7 - 8 | Heavy fry, hash browns, loin steaks, steaks. | 5 - 15 | Turn over when needed. |
| 9 | Boil water, cook pasta, sear meat (goulash, pot roast), deep-fry chips. | | |

8. HOB - CARE AND CLEANING



WARNING!

Refer to Safety chapters.

8.1 General information

- Clean the hob after each use.
- Always use cookware with a clean base.
- Scratches or dark stains on the surface have no effect on how the hob operates.
- Use a special cleaning agent suitable for the surface of the hob.
- Always use a scraper recommended for hobs with a glass surface. Use the scraper only as an additional tool for cleaning the glass after the standard cleaning procedure.



WARNING!

Do not use knives or any other sharp, metal tools to clean the glass surface.

8.2 Cleaning the hob

- **Remove immediately:** melted plastic, plastic foil, salt, sugar and food with sugar, otherwise, the dirt can cause damage to the hob. Take care to avoid burns. Use a special hob scraper on the glass surface at an acute angle and move the blade on the surface.
- **Remove when the hob is sufficiently cool:** limescale rings, water rings, fat stains, shiny metallic discoloration. Clean the hob with a moist cloth and a non-abrasive detergent. After cleaning, wipe the hob dry with a soft cloth.
- **Remove shiny metallic discoloration:** use a solution of water with vinegar and clean the glass surface with a cloth.

9. OVEN - DAILY USE



WARNING!

Refer to Safety chapters.

9.1 Oven functions



WARNING!

Do not pour any liquids into the cavity embossment before and during the cooking process. There is a risk of damage.

| Symbol | Oven function | Application |
|---|---------------------------|---|
|  | Off position | The oven is off. |
|  | Hot Air | To bake on up to two shelf positions at the same time and to dry food. Set the temperature 20 - 40 °C lower than for Conventional. |
|  | Pie / Pizza | To bake food on one shelf position for a more intensive browning and a crispy bottom. |
|  | Conventional / Aqua Clean | To bake and roast food on one shelf position. Refer to "Care and cleaning" chapter for more information about: Aqua Clean |
|  | Drying | To dry sliced fruit, vegetables and mushrooms. |
|  | Max Grill | To grill flat food in large quantities and to toast bread. |
|  | Turbo Grilling | To roast larger meat joints and poultry with bones on one shelf position. Also to make gratins and to brown. |
|  | Moist Fan Baking | This function was used to comply with the Energy Efficiency Class and Ecodesign Regulations (according to EU 65/2014 and EU 66/2014). Tests according to: IEC/EN 60350-1. The oven door should be closed during cooking so that the function is not interrupted and to ensure that the oven operates with the highest energy efficiency possible. When you use this function, the temperature in the cavity may differ from the set temperature. The heating power may be reduced. For general energy saving recommendations refer to "Energy Efficiency" chapter, Energy Saving. This function is designed to save energy during cooking. For the cooking instructions refer to "Hints and tips" chapter, Moist Fan Baking. When you use this function the lamp automatically turns off. |



You can defrost food by choosing Moist Fan Baking function without setting the temperature.

9.2 Activating and deactivating the oven

i It depends on the model if your appliance has knob symbols, indicators or lamps:

- The indicator comes on when the oven heats up.
- The lamp comes on when the oven operates.
- The symbol shows whether the knob controls one of the cooking zones, the oven functions or the temperature.

1. Turn the knob for the oven functions to select an oven function.
2. Turn the knob for the temperature to select a temperature.
3. To deactivate the oven turn the knobs for the oven functions and temperature to the off position.


9.3 Cooling fan

When the oven operates, the cooling fan turns on automatically to keep the surfaces of the oven cool. If you turn off the oven, the cooling fan stops.

9.4 Inserting the oven accessories


Deep pan:

Push the deep pan between the guide bars of the shelf support.



Wire shelf:

Push the shelf between the guide bars of the shelf support.



- All accessories have small indentations at the top of the right and left side to increase safety. The indentations are also anti-tip devices.
- The high rim around the shelf is a device which prevents cookware from slipping.

10. OVEN - HINTS AND TIPS



WARNING!
Refer to Safety chapters.



The temperature and baking times in the tables are guidelines only. They depend on the recipes and the quality and quantity of the ingredients used.

10.1 Baking

For the first baking, use the lower temperature.

You can extend the baking time by 10 – 15 minutes if you bake cakes on more than one shelf position.

Cakes and pastries at different heights do not always brown equally. There is no need to change the temperature setting if an unequal browning occurs. The differences equalize during baking.

Trays in the oven can distort during baking. When the trays are cold again, the distortions disappear.

10.2 Tips on baking

| Baking results | Possible cause | Remedy |
|---|--|--|
| The bottom of the cake is not baked sufficiently. | The shelf position is incorrect. | Put the cake on a lower shelf. |
| The cake sinks and becomes soggy or streaky. | The oven temperature is too high. | Next time set slightly lower oven temperature. |
| | The oven temperature is too high and the baking time is too short. | Next time set a longer baking time and lower oven temperature. |
| The cake is too dry. | The oven temperature is too low. | Next time set higher oven temperature. |
| | The baking time is too long. | Next time set shorter baking time. |
| The cake bakes unevenly. | The oven temperature is too high and the baking time is too short. | Next time set a longer baking time and lower oven temperature. |
| | The cake batter is not evenly distributed. | Next time spread the cake batter evenly on the baking tray. |
| The cake is not ready in the baking time specified in a recipe. | The oven temperature is too low. | Next time set a slightly higher oven temperature. |

10.3 Hot Air Baking

| Food | Temperature (°C) | Time (min) | Shelf position |
|-------------------------|------------------|------------|----------------|
| Bread rolls | 175 - 185 | 15 - 20 | 2 + 4 |
| Wholemeal rolls | 165 - 180 | 20 - 30 | 2 + 4 |
| Filled sandwiches | 170 - 180 | 15 - 20 | 2 + 4 |
| Pan loaf | 170 - 190 | 30 - 40 | 1 + 4 |
| Pretzels | 160 - 170 | 15 - 20 | 2 + 4 |
| White loaf / Round loaf | 170 - 180 | 35 - 45 | 2 + 4 |
| Wholemeal loaf | 160 - 170 | 35 - 45 | 2 + 4 |
| Rye bread, mix | 250 | - | 2 + 4 |
| - baking | 160 - 170 | 60 - 70 | 2 + 4 |
| Baguettes | 180 - 200 | 20 - 30 | 2 + 4 |
| Pancakes | 150 - 160 | 50 - 60 | 3 |
| Fruit cakes | 140 - 150 | 70 - 80 | 3 |

| Food | Temperature (°C) | Time (min) | Shelf position |
|---------------------------------|------------------|------------------------------|----------------|
| Muffins | 160 - 170 | 15 - 25 | 2 + 4 |
| Jam roll | 190 - 210 | 6 - 15 | 3 |
| Buns | 185 - 195 | 8 - 15 | 2 + 4 |
| Long loaf | 170 - 180 | 25 - 35 | 2 + 4 |
| Gingerbread | 160 - 170 | 8 - 15 | 2 + 4 |
| Dish cake | 150 - 160 | 30 - 40 | 2 + 4 |
| Sponge cakes / Madeira cakes | 150 - 160 | 50 - 60 | 2 |
| Meringues | 90 - 110 | 90 - 120 | 2 + 4 |
| Meringue bases | 90 - 110 | 90 - 120 | 2 + 4 |
| Biscuits | 150 - 160 | 10 - 20 | 2 + 4 |
| Choux pastry | 155 - 165 | 30 - 40 | 2 + 4 |
| Fruit tarts, short crust pastry | 150 - 160 | pre-baking, bases 10 - 15 | 2 + 4 |
| Fruit tarts, short crust pastry | 150 - 160 | finishing 35 - 45 | 2 + 4 |
| Fruit tarts, crumble pastry | 170 - 180 | 30 - 40 | 2 + 4 |

10.4 Hot Air Cooking

| Food | Temperature (°C) | Time (min) | Shelf position |
|-------------------------------------|------------------|-----------------------|----------------|
| Fish, boiling | 150 - 160 | _1) | 2 + 4 |
| Fish, frying | 165 - 175 | _ 1) | 2 + 4 |
| Meatloaf | 165 - 175 | 60 - 70 | 2 + 4 |
| Danish meatballs | 165 - 175 | 35 - 45 | 2 + 4 |
| Liver pâté | 165 - 175 | 65 - 75 | 2 + 4 |
| Potato gratin | 170 - 190 | 55 - 65 | 2 + 4 |
| Lasagne, home made | 170 - 190 | 60 - 70 | 2 + 4 |
| Lasagne, frozen | 170 - 190 | 30 - 45 ²⁾ | 2 + 4 |
| Pasta gratin | 165 - 175 | 40 - 50 | 2 + 4 |
| Chips, frozen | 180 - 200 | 30 - 45 ²⁾ | 2 + 4 |
| Tarts, home made - pre-baking, roll | 165 - 175 | 15 - 20 | 2 + 4 |

| Food | Temperature (°C) | Time (min) | Shelf position |
|------------------------------|------------------|-----------------------|----------------|
| Tarts, home made - finishing | 165 - 175 | 30 - 40 | 2 + 4 |
| Tarts, frozen | 170 - 190 | 25 - 35 ²⁾ | 2 + 4 |

1) When frying or boiling fish, the cooking time depends on the thickness of the fish. The fish is finished when the flesh is white. Test by sticking a fork into the fish. If the flesh comes easily away from the bone, the fish is cooked.

2) With cooking on two levels (double portion) the time is around 1/3 longer than that stated on the packaging. If the time given is 30 mins, then the preparation time will be around 30 + 10 = 40 min.

10.5 Conventional Baking

| Food | Temperature (°C) | Time (min) | Shelf position |
|------------------------------|------------------|------------|----------------|
| Bread rolls | 200 - 225 | 8 - 12 | 3 - 4 |
| Wholemeal rolls | 190 - 200 | 20 - 25 | 3 - 4 |
| Filled sandwiches | 200 - 225 | 10 - 12 | 3 - 4 |
| Ciabatta rolls | 210 - 230 | 10 - 20 | 3 - 4 |
| Foccacia | 220 - 230 | 15 - 20 | 3 - 4 |
| Pita bread | 250 | 5 - 15 | 3 - 4 |
| Pretzels | 180 - 200 | 12 - 15 | 3 - 4 |
| White loaf | 190 - 210 | 25 - 40 | 1 - 2 |
| Ciabatta | 210 - 220 | 15 - 25 | 1 - 2 |
| Wholemeal loaf | 180 - 200 | 35 - 45 | 1 - 2 |
| Rye bread baking | 180 - 200 | 55 - 65 | 1 |
| - baking | 190 | 55 - 65 | 1 |
| Baguettes | 220 - 230 | 15 - 30 | 3 - 4 |
| Pancake | 170 - 180 | 50 - 60 | 2 - 3 |
| Dish cake | 170 - 180 | 35 - 45 | 3 - 4 |
| Sponge cakes / Madeira cakes | 170 - 180 | 40 - 50 | 1 - 2 |
| Sandwich cake, roll | 200 - 225 | 8 - 12 | 3 - 4 |
| Meringues | 90 - 110 | 90 - 120 | 3 - 4 |
| Meringue bases | 90 - 110 | 90 - 120 | 3 - 4 |
| Biscuits | 160 - 180 | 6 - 15 | 3 - 4 |
| Choux pastry | 170 - 190 | 30 - 45 | 3 - 4 |

| Food | Temperature (°C) | Time (min) | Shelf position |
|---------------------------------|------------------|-----------------------------|----------------|
| Swiss rolls | 190 - 210 | 10 - 12 | 3 - 4 |
| Fruit tarts, short crust pastry | 175 - 200 | pre-baking, roll 10 - 15 | 3 - 4 |
| Fruit tarts, short crust pastry | 170 - 180 | finishing 35 - 45 | 3 - 4 |
| Fruit tarts, crumble pastry | 190 - 200 | 25 - 35 | 3 - 4 |
| Marzipan ring cake | 210 - 230 | 10 - 12 | 2 |

10.6 Conventional Cooking

| Food | Temperature (°C) | Time (min) | Shelf position |
|-------------------------------------|------------------|-----------------------|----------------|
| Fish, boiling | 160 - 170 | _1) | 3 |
| Fish, frying | 180 - 200 | _1) | 3 |
| Meatloaf | 175 - 200 | 45 - 60 | 3 |
| Danish meatballs | 175 - 200 | 30 - 45 | 3 |
| Liver pâté | 180 - 200 | 50 - 60 | 3 |
| Gratin | 180 - 200 | 50 - 60 | 3 |
| Potato gratin | 190 - 210 | 55 - 65 | 3 |
| Lasagne, home made | 190 - 210 | 50 - 60 | 3 |
| Lasagne, frozen | 175 - 200 | 30 - 45 ²⁾ | 3 |
| Pasta gratin | 180 - 200 | 30 - 40 | 3 |
| Chips, frozen | 225 - 250 | 20 - 30 ²⁾ | 3 |
| Tarts, home made - pre-baking, roll | 190 - 210 | 15 - 25 | 3 |
| Tarts, home made - finishing | 190 - 210 | 20 - 30 | 3 |
| Tarts, frozen | 200 - 225 | 20 - 30 ²⁾ | 3 |

¹⁾ When frying or boiling fish, the cooking time depends on the thickness of the fish. The fish is finished when the flesh is white. Test by sticking a fork into the fish. If the flesh comes easily away from the bone, the fish is cooked.

²⁾ With cooking on two levels (double portion) the time is around 1/3 longer than that stated on the packaging. If the time given is 30 min, then the preparation time will be around 30 + 10 = 40 min.

10.7 Pizza Table

| Food | Temperature (°C) | Time (min) | Shelf position |
|--|-------------------------|------------|----------------|
| Ciabatta rolls | 200 - 220 | 10 - 20 | 2 |
| Foccacia | 220 - 230 | 10 - 20 | 2 |
| Ciabatta | 190 - 200 | 15 - 25 | 2 |
| Fruit tarts, short crust pastry | 170 - 180 | 35 - 45 | 2 |
| Fruit tarts, crumble pastry | 175 - 200 | 25 - 35 | 2 |
| Pizza, home made (thick - with a lot of topping) | 180 - 200 | 25 - 35 | 1 |
| Pizza, home made (thin crust) | 200 - 230 ¹⁾ | 15 - 20 | 1 |
| Pizza, frozen | 190 - 200 | 15 - 20 | 3 |
| Tarts, home made pre-baking, roll | 175 - 200 | 35 - 45 | 3 |
| Tarts, home made finishing | 175 - 200 | 35 - 45 | 3 |
| Tarts, frozen | 190 - 210 | 15 - 25 | 3 |

1) Preheat the oven.

10.8 Moist Fan Baking

Bread and pizza

| Food | Temperature (°C) | Time (min) | Shelf position |
|--------------------|------------------|------------|----------------|
| Buns | 180 | 25 - 35 | 3 |
| Frozen pizza 350 g | 190 | 25 - 35 | 3 |

Cakes in baking tray

| Food | Temperature (°C) | Time (min) | Shelf position |
|------------|------------------|------------|----------------|
| Swiss roll | 180 | 20 - 30 | 3 |
| Brownie | 180 | 30 - 40 | 3 |

Cakes in tin

| Food | Temperature (°C) | Time (min) | Shelf position |
|-------------------|------------------|------------|----------------|
| Soufflé | 200 | 30 - 40 | 3 |
| Sponge flan base | 180 | 20 - 30 | 3 |
| Victoria sandwich | 150 | 25 - 35 | 3 |

Fish

| Food | Temperature (°C) | Time (min) | Shelf position |
|-----------------------|------------------|------------|----------------|
| Fish in pouches 300 g | 180 | 25 - 35 | 3 |
| Whole fish 200 g | 180 | 25 - 35 | 3 |
| Fish fillet 300 g | 180 | 25 - 35 | 3 |

Meat

| Food | Temperature (°C) | Time (min) | Shelf position |
|---------------------|------------------|------------|----------------|
| Meat in pouch 250 g | 200 | 25 - 35 | 3 |
| Meat skewers 500 g | 200 | 30 - 40 | 3 |

Small baked items

| Food | Temperature (°C) | Time (min) | Shelf position |
|-----------------------------|------------------|------------|----------------|
| Cookies | 180 | 25 - 35 | 3 |
| Macaroons | 160 | 25 - 35 | 3 |
| Muffins | 180 | 25 - 35 | 3 |
| Savoury cracker | 170 | 20 - 30 | 3 |
| Short crust pastry biscuits | 150 | 25 - 35 | 3 |
| Tartelettes | 170 | 15 - 25 | 3 |

Vegetarian

| Food | Temperature (°C) | Time (min) | Shelf position |
|---------------------------------|------------------|------------|----------------|
| Mixed vegetables in pouch 400 g | 180 | 25 - 35 | 3 |
| Omelette | 200 | 20 - 30 | 3 |
| Vegetables on tray 700 g | 180 | 25 - 35 | 3 |

10.9 Tips on Roasting

Use heat-resistant ovenware.

Roast lean meat covered (you can use aluminium foil).

Roast large meat joints directly in the tray.

Put some water in the tray to prevent dripping fat from burning.

Turn the roast after 1/2 - 2/3 of the cooking time.

Roast meat and fish in large pieces (1 kg or more).

If level one is suggested put the food directly on the baking tray

Baste meat joints with their own juice several times during roasting.

10.10 Hot Air Roasting

Beef

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|--------------------------|------------------|-----------------|----------------|
| Roast beef ¹⁾ | 125 | 80 - 120 | 2 - 3 |
| Rump steak - browning | 200 | total 10 | 2 - 3 |
| Rump steak - roasting | 150 | 50 - 60 | 2 - 3 |
| Roast beef | 160 | 90 - 120 | 1 - 2 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

Veal

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|------------------------------|------------------|-----------------|----------------|
| Fillet of beef ¹⁾ | 160 | 60 - 70 | 2 - 3 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

Lamb

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|-------------------------|------------------|-----------------|----------------|
| Leg / shoulder / saddle | 160 | 80 - 100 | 2 |

Pork

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|--------------------------|------------------|-----------------|----------------|
| Roast pork ¹⁾ | 175 | 60 - 70 | 2 - 3 |
| Pork loin ¹⁾ | 175 | 60 | 2 - 3 |
| Neck fillets | 160 | 90 - 120 | 2 - 3 |
| Ham | 150 | 60 - 100 | 1 - 2 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

Poultry

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|--------------------|------------------|-----------------|----------------|
| Chicken, parted | 180 | 55 - 65 | 2 - 3 |
| Duck ¹⁾ | 150 | 55 - 65 | 2 - 3 |

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|----------------------------------|------------------|----------------------|----------------|
| Duck slow roasting ¹⁾ | 130 | total around 5 hours | 2 - 3 |
| Roast turkey, stuffed | 150 | 50 - 60 | 1 - 2 |
| Turkey breast | 175 | 70 - 80 | 2 - 3 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

10.11 Conventional Roasting

Beef

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|--------------------------|------------------|-----------------|----------------|
| Roast beef ¹⁾ | 125 | 80 - 120 | 2 - 3 |
| Rump steak - browning | 225 | total 10 | 2 - 3 |
| Rump steak - roasting | 160 | 50 - 60 | 2 - 3 |
| Roast beef | 180 | 90 - 120 | 1 - 3 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

Veal

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|------------------------------|------------------|-----------------|----------------|
| Fillet of beef ¹⁾ | 180 | 60 - 70 | 2 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

Lamb

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|----------------------|------------------|-----------------|----------------|
| Leg / shoulder / rib | 180 | 80 - 100 | 2 |

Pork

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|--------------------------|------------------|-----------------|----------------|
| Roast pork ¹⁾ | 200 | 60 - 70 | 3 |
| Pork loin ¹⁾ | 200 | 60 | 3 |
| Neck fillets | 180 | 90 - 120 | 3 |

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|------|------------------|-----------------|----------------|
| Ham | 160 | 60 - 100 | 2 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

Poultry

| Food | Temperature (°C) | Time (min / kg) | Shelf position |
|----------------------------------|------------------|----------------------|----------------|
| Chicken, parted | 200 | 55 - 65 | 2 |
| Duck ¹⁾ | 160 | 55 - 65 | 2 |
| Duck slow roasting ¹⁾ | 130 | total around 5 hours | 2 |
| Roast turkey, stuffed | 160 | 50 - 60 | 2 |
| Turkey breast | 200 | 70 - 80 | 2 |
| Whole chicken | 220 | 60 - 90 | 2 |

¹⁾ Other. Can be browned off after roasting under the grill or with top / bottom heat at 250°C. If you are using a meat probe, remove it before grilling.

10.12 Roasting with Turbo Grilling

Beef

| Food | Quantity | Temperature (°C) | Time (min) | Shelf position |
|---------------------------------|----------------------|-------------------------|------------|----------------|
| Roast beef or fillet: rare | per cm. of thickness | 190 - 200 ¹⁾ | 5 - 6 | 1 |
| Roast beef or fillet: medium | per cm. of thickness | 180 - 190 | 6 - 8 | 1 |
| Roast beef or fillet: well done | per cm. of thickness | 170 - 180 | 8 - 10 | 1 |

¹⁾ Preheat the oven.

Pork

| Food | Quantity | Temperature (°C) | Time (min) | Shelf position |
|---------------------------|--------------|------------------|------------|----------------|
| Shoulder, neck, ham joint | 1 - 1.5 kg | 160 - 180 | 90 - 120 | 1 |
| Chop, spare rib | 1 - 1.5 kg | 170 - 180 | 60 - 90 | 1 |
| Meat loaf | 750 g - 1 kg | 160 - 170 | 50 - 60 | 1 |
| Pork knuckle (pre-cooked) | 750 g - 1 kg | 150 - 170 | 90 - 120 | 1 |

Veal

| Food | Quantity | Temperature (°C) | Time (min) | Shelf position |
|-----------------|------------|------------------|------------|----------------|
| Roast veal | 1 kg | 160 - 180 | 90 - 120 | 1 |
| Knuckle of veal | 1.5 - 2 kg | 160 - 180 | 120 - 150 | 1 |

Lamb

| Food | Quantity | Temperature (°C) | Time (min) | Shelf position |
|-------------------------|------------|------------------|------------|----------------|
| Leg of lamb, roast lamb | 1 - 1.5 kg | 150 - 170 | 100 - 120 | 1 |
| Saddle of lamb | 1 - 1.5 kg | 160 - 180 | 40 - 60 | 1 |

Poultry

| Food | Quantity | Temperature (°C) | Time (min) | Shelf position |
|------------------|------------------|------------------|------------|----------------|
| Poultry portions | 200 - 250 g each | 200 - 220 | 30 - 50 | 1 |
| Duck | 1.5 - 2 kg | 180 - 200 | 80 - 100 | 1 |
| Goose | 3.5 - 5 kg | 160 - 180 | 120 - 180 | 1 |
| Turkey | 2.5 - 3.5 kg | 160 - 180 | 120 - 180 | 1 |
| Turkey | 4 - 6 kg | 140 - 160 | 150 - 240 | 1 |
| Whole chicken | 1 - 1.5 kg | 180 - 200 | 60 - 90 | 2 |


10.13 Grilling in general

**WARNING!**

Always grill with the oven door closed.

- **Always grill with the maximum temperature setting.**
- Set the shelf into the shelf position as recommended in the grilling table.
- If the first shelf position is recommended put the food directly on the baking tray.
- Always place the deep pan to collect fat on the first shelf position.

- Grill only flat pieces of meat or fish.



The grilling area is set in centre of the shelf.

10.14 Fast Grilling 

| Food | Temperature (°C) | Time (min) | | Shelf position |
|---------|------------------|------------|----------|----------------|
| | | 1st side | 2nd side | |
| Burgers | max 1) | 9 - 15 | 8 - 13 | 4 |

| Food | Temperature (°C) | Time (min) | | Shelf position |
|----------------------------|------------------|------------|----------|----------------|
| | | 1st side | 2nd side | |
| Pork fillet | max | 10 - 12 | 6 - 10 | 4 |
| Sausages | max | 10 - 12 | 6 - 8 | 4 |
| Fillet steaks, veal steaks | max | 7 - 10 | 6 - 8 | 4 |
| Toast | max 1) | 1 - 4 | 1 - 4 | 4 - 5 |
| Toast with topping | max | 6 - 8 | - | 4 |

1) Pre-heat the oven

10.15 Drying

Cover the oven shelves with baking parchment.

For best results: deactivate the appliance after half the time required. Open the

appliance door and let the appliance cool down. After that finish the drying process.

Vegetables

| Food | Temperature (°C) | Time (h) | Shelf position | |
|---------------------|------------------|----------|----------------|-------------|
| | | | 1 position | 2 positions |
| Beans | 60 - 70 | 6 - 8 | 3 | 2 / 4 |
| Peppers | 60 - 70 | 5 - 6 | 3 | 2 / 4 |
| Vegetables for sour | 60 - 70 | 5 - 6 | 3 | 2 / 4 |
| Mushrooms | 50 - 60 | 6 - 8 | 3 | 2 / 4 |
| Herbs | 40 - 50 | 2 - 3 | 3 | 2 / 4 |

Fruit

| Food | Temperature (°C) | Time (h) | Shelf position | |
|--------------|------------------|----------|----------------|-------------|
| | | | 1 position | 2 positions |
| Plums | 60 - 70 | 8 - 10 | 3 | 2 / 4 |
| Apricots | 60 - 70 | 8 - 10 | 3 | 2 / 4 |
| Apple slices | 60 - 70 | 6 - 8 | 3 | 2 / 4 |
| Pears | 60 - 70 | 6 - 9 | 3 | 2 / 4 |

10.16 Information for test institutes

| Food | Function | Temperature (°C) | Time (min) | Accessories | Shelf position |
|--|--------------|------------------|------------|---------------------|----------------|
| Small cakes (20 small cakes per tray) | Conventional | 170 | 20 - 30 | Tray | 4 |
| Small cakes (20 small cakes per tray) ¹⁾ | Hot Air | 150 | 20 - 30 | Tray | 2 |
| Small cakes (20 small cakes per tray) ¹⁾ | Hot Air | 150 | 25 - 35 | Tray / Dripping Pan | 1 + 4 |
| Apple pie, 2 tins (ø 20 cm) on the grid, diagonally shifted | Conventional | 180 | 70 - 90 | Grid | 1 |
| Apple pie, 2 tins (ø 20 cm) on the grid, diagonally shifted | Hot Air | 160 | 70 - 90 | Grid | 2 |
| Apple pie, 2 tins (ø 20 cm) on the grid, diagonally shifted | Pie / Pizza | 160 | 60 - 80 | Grid | 2 |
| Fatless sponge cake, 1 tin (ø 26 cm) on the grid | Conventional | 170 | 30 - 40 | Grid | 3 |
| Fatless sponge cake, 1 tin (ø 26 cm) on the grid | Hot Air | 150 | 35 - 45 | Grid | 2 |
| Fatless sponge cake, 1 tin (ø 26 cm) on the grid ¹⁾ | Hot Air | 160 | 25 - 35 | Grid | 1 + 4 |
| Shortbread/Pastry strip | Hot Air | 140 | 20 - 35 | Tray | 3 |
| Shortbread/Pastry strip | Hot Air | 140 | 20 - 30 | Tray | 1 + 4 |
| Shortbread/Pastry strip | Conventional | 160 | 20 - 35 | Tray | 3 |
| Toast ¹⁾ | (Max) Grill | Max | 1 - 5 | Grid | 4 |

| Food | Function | Temperature (°C) | Time (min) | Accessories | Shelf position |
|-------------|----------|------------------|---|---------------------|----------------|
| Beef burger | Grill | Max | 15 - 20 first side. 10 - 15 second side. | Grid / Dripping pan | 4 + 1 |

1) Preheat the oven for 10 minutes.

11. OVEN - CARE AND CLEANING



WARNING!
Refer to Safety chapters.

11.1 Notes on cleaning



Cleaning Agents

Clean the front of the appliance only with a microfibre cloth with warm water and a mild detergent.

Use a cleaning solution to clean metal surfaces.

Clean stains with a mild detergent.



Everyday Use

Clean the cavity after each use. Fat accumulation or other residue may cause fire.

Do not store the food in the appliance for longer than 20 minutes. Dry the cavity only with a microfibre cloth after each use.



Accessories

Clean all accessories after each use and let them dry. Use only a microfibre cloth with warm water and a mild detergent. Do not clean the accessories in a dishwasher.

Do not clean the non-stick accessories using abrasive cleaner or sharp-edged objects.

11.2 Stainless steel or aluminium ovens


Clean the oven door with a damp cloth or sponge only. Dry it with a soft cloth.

Do not use steel wool, acids or abrasive materials as they can damage the oven surface. Clean the oven control panel with the same precautions.


11.3 Removing the shelf supports

To clean the oven, remove the shelf supports.

1. Pull the front of the shelf support away from the side wall.



2. Pull the rear end of the shelf support away from the side wall and remove it.



Install the shelf supports in the opposite sequence.



CAUTION!

Make sure that the longer fixing wire is in the front. The ends of the two wires must point to the rear. Incorrect installation can cause damage to the enamel.


11.4 How to use: Aqua Clean

This cleaning procedure uses humidity to remove remaining fat and food particles from the appliance.

1. Pour water into the cavity embossment: 250ml.
2. Set the function .
3. Set the temperature to 90 °C.
4. Let the appliance work for 30 min.
5. Turn off the appliance.
6. Wait until the appliance is cold. Dry the cavity with a soft cloth.

11.5 Removing the oven door

To make the cleaning easier, remove the door.



1. Open the door fully.
2. Move the slider until you hear a click.
3. Close the door until the slider locks.
4. Remove the door.

To remove the door, pull the door outwards first from one side, and then the other.


When the cleaning procedure is completed, insert the oven door in the opposite sequence. Make sure that you hear a click when you insert the door. Use force if necessary.

11.6 Removing and cleaning the door glasses




The door glass in your product can be different in type and shape from the examples you see in the images. The number of glasses can also be different.

1. Hold the door trim B on the top edge of the door at the two sides and push inwards to release the clip seal.



2. Pull the door trim to the front to remove it.
3. Hold the door glass panels on their top edge one by one and pull them upwards from the guide.



4. Clean the door glass panels. To install panels, do the same steps in reverse.

11.7 How to remove: grill




WARNING!
Deactivate the appliance before you remove the heating element. Make sure that the appliance is cold. There is a risk of burns.

Remove the shelf supports.

You can remove the heating element to clean the oven ceiling more easily.

1. Remove the screw which holds the heating element. For the first time, use a screwdriver.



2. Carefully pull the heating element down.
3. Clean the oven ceiling with a soft cloth with warm water and a cleaning agent, and let it dry.

Install the heating element in the opposite sequence.

Install the shelf supports.



WARNING!
Make sure that the heating element is correctly installed and that it does not fall down.

11.8 Replacing the lamp



WARNING!
Risk of electric shock.
The lamp can be hot.

1. Turn off the oven. Wait until the oven is cold.
2. Disconnect the oven from the mains.
3. Put a cloth on the bottom of the cavity.

The back lamp



The lamp glass cover is at the back of the cavity.

1. Turn the lamp glass cover counterclockwise to remove it.
2. Clean the glass cover.
3. Replace the oven lamp with a suitable 300 °C heat-resistant oven lamp.
Use the same oven lamp type.
4. Install the glass cover.

11.9 The drawer



WARNING!
Do not put food inside the drawer.



WARNING!
Do not keep flammable items such as cleaning materials, plastic bags, oven gloves, paper, cleaning products, aerosols, plastic items) in the drawer. When you use the oven, the drawer can become hot. There is a risk of fire.

The drawer below the oven can be removed for cleaning.

Removing the drawer:

1. Pull the drawer out until it stops.
 2. Lift the drawer slightly, so that can be lifted upwards at an angle of the drawer guides.
- To install the drawer, follow the procedure in reverse.

12. TROUBLESHOOTING



WARNING!
Refer to Safety chapters.

12.1 What to do if...

| Problem | Possible cause | Remedy |
|--|--|---|
| You cannot activate the appliance. | The appliance is not connected to an electrical supply or it is connected incorrectly. | Check if the appliance is correctly connected to the electrical supply. |
| You cannot activate the appliance. | The fuse is blown. | Make sure that the fuse is the cause of the malfunction. If the fuse is blown again and again, contact a qualified electrician. |
| Residual heat indicator does not come on. | The zone is not hot because it operated only for a short time. | If the zone operated sufficiently long to be hot, speak to an Authorised Service Centre. |
| The oven does not heat up. | The oven is deactivated. | Activate the oven. |
| The oven does not heat up. | The necessary settings are not set. | Make sure that the settings are correct. |
| The lamp does not operate. | The lamp is defective. | Replace the lamp. |
| Steam and condensation settle on the food and in the cavity of the oven. | You left the dish in the oven for too long. | Do not leave the dishes in the oven for longer than 15 - 20 minutes after the cooking process ends. |

12.2 Service data

If you cannot find a solution to the problem yourself, contact your dealer or an Authorised Service Centre.

The necessary data for the service centre is on the rating plate. The rating plate is on the front frame of the appliance cavity. Do not remove the rating plate from the appliance cavity.

We recommend that you write the data here:

Model (MOD.)

.....

We recommend that you write the data here:

Product number
(PNC)

Serial number
(S.N.)

13. ENERGY EFFICIENCY

13.1 Product Information according to EU Ecodesign Regulations for Hob

| | | |
|---|--------------------------------|-------------|
| Model identification | VKK60010HV | |
| Type of hob | Hob inside Freestanding Cooker | |
| Number of cooking zones | 4 | |
| Heating technology | Radiant Heater | |
| Diameter of circular cooking zones (Ø) | Left front | 21.0 cm |
| | Left rear | 14.5 cm |
| | Right front | 14.5 cm |
| | Right rear | 18.0 cm |
| Energy consumption per cooking zone (EC electric cooking) | Left front | 182.3 Wh/kg |
| | Left rear | 181.8 Wh/kg |
| | Right front | 181.8 Wh/kg |
| | Right rear | 182.1 Wh/kg |
| Energy consumption of the hob (EC electric hob) | 182.0 Wh/kg | |

IEC/EN 60350-2 - Household electric cooking appliances - Part 2: Hobs - Methods for measuring performance.

13.2 Hob - Energy saving

You can save energy during everyday cooking if you follow the hints below.

- When you heat up water, use only the amount you need.
- If it is possible, always put the lids on the cookware.
- Before you activate the cooking zone put the cookware on it.
- The cookware bottom should have the same diameter as the cooking zone.
- Put the smaller cookware on the smaller cooking zones.
- Put the cookware directly in the centre of the cooking zone.
- Use the residual heat to keep the food warm or to melt it.

13.3 Product Information Sheet and Product Information according to EU Energy Labelling and Ecodesign Regulations for Oven

| | |
|--|----------------------|
| Supplier's name | Voss |
| Model identification | VKK60010HV 947942535 |
| Energy Efficiency Index | 95.3 |
| Energy efficiency class | A |
| Energy consumption with a standard load, conventional mode | 0.95 kWh/cycle |

| | |
|--|---------------------------------|
| Energy consumption with a standard load, fan-forced mode | 0.82 kWh/cycle |
| Number of cavities | 1 |
| Heat source | Electricity |
| Volume | 73 l |
| Type of oven | Oven inside Freestanding Cooker |
| Mass | 56.5 kg |

IEC/EN 60350-1 - Household electric cooking appliances - Part 1: Ranges, ovens, steam ovens and grills - Methods for measuring performance.

13.4 Oven - Energy saving

Following tips below will help you save energy when using your appliance.

Make sure that the appliance door is closed when the appliance operates. Do not open the appliance door too often during cooking. Keep the door gasket clean and make sure it is well fixed in its position.

Use metal cookware and dark, non-reflective tins and containers to improve energy saving.

Do not preheat the appliance before cooking unless specifically recommended.

Keep breaks between baking as short as possible when you prepare a few dishes at one time.

Cooking with fan

When possible, use the cooking functions with fan to save energy.

13.5 Product Information for power consumption and maximum time to reach applicable low power mode

| | |
|--|--------|
| Power consumption in off mode | 0.3 W |
| Maximum time needed for the equipment to automatically reach the applicable low power mode | 20 min |

Residual heat

When the cooking duration is longer than 30 min, reduce the appliance temperature to minimum 3 - 10 min before the end of cooking. The residual heat inside the appliance will continue to cook.

Use the residual heat to keep the food warm or warm up other dishes.

Keep food warm

Choose the lowest possible temperature setting to use residual heat and keep the food warm.

Moist Fan Baking

Function designed to save energy during cooking.

14. ENVIRONMENTAL CONCERNS

Recycle materials with the symbol .
Put the packaging in relevant containers

to recycle it. Help protect the environment and human health by

recycling waste of electrical and electronic appliances. Do not dispose of appliances marked with the symbol  with the household waste. Return the product to your local recycling facility or contact your municipal office.

Electrolux Appliances AB - Contact
Address: Al. Powstancow Slaskich 26,
30-570 Krakow, Poland

