

Futher information and explanations are available online:



Table of contents

1 Safety41.1 General information41.2 Intended use41.3 Restriction on user group41.4 Safe installation51.5 Safe use71.6 Safe cleaning and maintenance9	
2 Preventing material damage 11	
3 Environmental protection and saving energy	
4 Installation and connection	
5 Familiarising yourself with your appliance	
6 Display 17	
7 Buttons 19	
8 Dryness level	

9 Programmes	22
10 Accessories	24
11 Laundry 11.1 Preparing the laundry	
12 Basic operation	25
settings	26
"Ready in" time	26 26
12.10 Switching off the appliance 12.11 Fluff filter 12.12 Filter system on the base	27
unit 12.13 Condensation container	28 30
13 Childproof lock	31
13.1 Activating the childproof lock	31
lock	
14 Basic settings 14.1 Overview of the basic set-	32
tings	32
14.2 Changing the basic set- tings	33

15 Cleaning and servicing	33
15.1 Tips on cleaning and care 15.2 Base unit	
15.3 Moisture sensor	
16 Troubleshooting	37
17 Transportation, storage and disposal	41
17.1 Preparing the appliance for transportation	41
18 Customer Service 18.1 Product number (E-Nr.) and	42
production number (FD)	42
19 Consumption values	43
20 Technical data	44



1 Safety

Observe the following safety instructions.

1.1 General information



- Read this instruction manual carefully.
- Keep the instruction manual and the product information safe for future reference or for the next owner.
- Do not connect the appliance if it has been damaged in transit.

1.2 Intended use

Only use this appliance:

- For drying and freshening up fabrics that are washed with water and suitable for dryers.
- In private households and in enclosed spaces in a domestic environment.
- Up to an altitude of max. 4000 m above sea level.

1.3 Restriction on user group

This appliance may be used by children aged 8 or over and by people who have reduced physical, sensory or mental abilities or inadequate experience and/or knowledge, provided that they are supervised or have been instructed on how to use the appliance safely and have understood the resulting dangers.

Do not let children play with the appliance.

Cleaning and user maintenance must not be performed by children unless they are being supervised.

Keep children under the age of 3 years and pets away from the appliance.

1.4 Safe installation

Take note of the safety instructions when installing the appliance.

Incorrect installation is dangerous.

- ► Connect and operate the appliance only in accordance with the specifications on the rating plate.
- Connect the appliance to a power supply with alternating current only via a properly installed socket with earthing.
- ► The protective conductor system of the domestic electrical installation must be properly installed. The installation must have a sufficiently large cross section.
- ▶ When using a residual current circuit breaker, only use a type with the mark.
- ► Never equip the appliance with an external switching device, e.g. a timer or remote control.
- Never connect the appliance to a circuit that is regularly switched on and off by the energy supplier.
- ▶ When the appliance is installed, the mains plug of the power cord must be freely accessible. If free access is not possible, an all-pole isolating switch must be installed in the permanent electrical installation according to the installation regulations.
- ► When installing the appliance, check that the power cable is not trapped or damaged.

If the insulation of the power cord is damaged, this is dangerous.

- Never let the power cord come into contact with hot appliance parts or heat sources.
- ► Never let the power cord come into contact with sharp points or edges.
- ▶ Never kink, crush or modify the power cord.

↑ WARNING – Risk of fire!

It is dangerous to use an extended power cord and non-approved adapters.

- ▶ Do not use extension cables or multiple socket strips.
- Only use adapters and power cords approved by the manufacturer.

en Safety

▶ If the power cord is too short and a longer one is not available, please contact an electrician to have the domestic installation adapted.

⚠ WARNING – Risk of injury!

The high weight of the appliance may result in injury when lifted.

▶ Do not lift the appliance on your own.

If this appliance is not correctly installed in a washer-dryer stack, the installed appliance may fall.

- Only stack the dryer on a washing machine using the connection kit from the dryer manufacturer
 - → "Accessories", Page 24. No other installation method is permitted.
- ▶ Do not install the appliance in a washer-dryer stack if the dryer manufacturer does not offer a suitable connection kit.
- ▶ Do not install appliances from different manufacturers and with varying depths and widths in a washer-dryer stack.
- ▶ Do not install a washer-dryer stack on a platform; the appliances may tip over.

⚠ WARNING – Risk of suffocation!

Children may put packaging material over their heads or wrap themselves up in it and suffocate.

- ► Keep packaging material away from children.
- ▶ Do not let children play with packaging material.

△ CAUTION – Risk of injury!

The appliance may vibrate or move when in use.

- ▶ Place the appliance on a clean, even, solid surface.
- ► Align the appliance using the appliance feet and a spirit level. If hoses and power cords have been laid incorrectly, this causes a tripping hazard.
- Lay hoses and power cords in such a way that there is no risk of tripping.

If the appliance is moved by holding onto protruding components, such as the appliance door, the parts may break off.

▶ Do not move the appliance by holding onto protruding parts.

△ CAUTION – Risk of cutting!

Touching sharp edges on the appliance may lead to cuts.

- ▶ Do not touch the sharp edges on the appliance.
- Wear protective gloves when installing and transporting the appliance.

1.5 Safe use

If the appliance or the power cord is damaged, this is dangerous.

- ► Never operate a damaged appliance.
- ► Never pull on the power cord to unplug the appliance. Always unplug the appliance at the mains.
- ▶ If the appliance or the power cord is damaged, immediately unplug the power cord or switch off the fuse in the fuse box.
- ► Call customer services. → Page 42

An ingress of moisture can cause an electric shock.

- ► Only use the appliance in enclosed spaces.
- ► Never expose the appliance to intense heat or humidity.
- ▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

△ WARNING – Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- ▶ Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- ▶ With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

↑ WARNING – Risk of suffocation!

Children may breathe in or swallow small parts, causing them to suffocate.

- ► Keep small parts away from children.
- ▶ Do not let children play with small parts.

⚠ WARNING – Risk of explosion!

If there is coal dust or flour in the air around the appliance, this may cause an explosion.

► Keep the area around the appliance clean during operation.

⚠ WARNING – Risk of poisoning!

Condensation water from this appliance is not suitable for drinking and may be contaminated with fluff.

Do not drink or reuse the condensation water from the appliance.

Detergents and care products may result in poisoning if consumed.

- ▶ If accidentally swallowed, seek medical advice.
- ► Keep detergents and care products out of the reach of children.

⚠ WARNING – Risk of fire!

The refrigerant R290 in this appliance is environmentally friendly yet combustible and may ignite if it comes into contact with open flames or ignition sources.

► Keep naked flames and ignition sources away from the appli-



⚠ WARNING – Risk of explosion!

If there is any residual material left in the fluff filter, this may ignite during the drying process.

Clean the fluff filter regularly.

Highly flammable objects such as lighters or matches may ignite during the drying process.

► Remove all highly flammable objects from any pockets in your laundry before the drying process.

Unwashed laundry that has come into contact with solvents, oil, wax, wax remover, paint, grease or stain remover may ignite when drying is in progress.

▶ Do not place laundry in this appliance to be dried if the laundry has not been washed first.

- ► Rinse the laundry thoroughly with warm water and detergent before drying it in the machine.
- ▶ Do not use the appliance if industrial chemicals have been used to clean the laundry beforehand.

If drying is interrupted early, the laundry is not cooled sufficiently and may ignite.

- ▶ Do not interrupt the drying programme early.
- ► If drying is interrupted early, remove the laundry immediately and spread it out.

△ CAUTION – Risk of injury!

The covering plate may break if you stand on or climb onto the appliance.

▶ Do not stand on or climb onto the appliance.

The appliance may tip over if you sit on or lean against the open door.

- ▶ Do not sit on or lean against the appliance door.
- ▶ Do not place any objects on the appliance door.

Reaching into the drum while it is still turning may cause hand iniuries.

Wait for the drum to come to a complete stop before reaching inside.

1.6 Safe cleaning and maintenance

Take note of the safety instructions when cleaning and performing maintenance work on the appliance.

Incorrect repairs are dangerous.

- Repairs to the appliance should only be carried out by trained specialist staff.
- ▶ Only use genuine spare parts when repairing the appliance.
- If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

en Safety

An ingress of moisture can cause an electric shock.

▶ Do not use steam- or high-pressure cleaners, hoses or sprays to clean the appliance.

⚠ WARNING – Risk of injury!

The use of non-original spare parts and non-original accessories is dangerous.

► Only use the manufacturer's original spare parts and original accessories.

⚠ WARNING – Risk of poisoning!

Poisonous fumes may be given off if you use cleaning agents that contain solvents.

▶ Do not use cleaning agents that contain solvents.

2 Preventing material damage

Follow these instructions to avoid material damage and damage to the appliance.

ATTENTION!

The functionality of the appliance may be impaired if you use the wrong quantity of fabric softener, detergent, care product or cleaning agent.

Follow the dosage recommendations from the manufacturer.

Exceeding the maximum load capacity impairs the function of the appliance.

- Observe the maximum load capacity for each programme and do not exceed it.
- → "Programmes", Page 22 The function of the appliance may be impaired if the appliance overheats.
- During operation, keep the air inlet on the appliance clear.
- Make sure that the area is adequately ventilated.

Light objects such as hair and fluff may be sucked into the air inlet on the appliance during operation and impair the function of the appliance.

- Keep the area around the appliance clean during operation.
- Keep light objects away from the appliance.

If you operate the appliance without a fluff guard (e.g. fluff filter, fluff collector, filter mat, etc., depending on appliance specifications), or if the fluff quard is incomplete or defective, this may result in damage to the appliance.

Do not operate the appliance without a fluff guard, or with a fluff guard that is incomplete or defective.

Foam and foam rubber may deform or melt during the drying process.

Do not dry laundry that contains foam or foam rubber.

Unsuitable cleaning products may damage the surfaces of the appli-

- ▶ Do not use harsh or abrasive detergents.
- Do not use cleaning products with a high alcohol content.
- Do not use hard scouring pads or cleaning sponges.
- Clean the appliance with nothing but water and a soft, damp cloth.
- ► Remove all detergent residue, spray residue or other residues immediately if they come into contact with the appliance.

3 Environmental protection and saving energy

3.1 Disposing of packaging

The packaging materials are environmentally compatible and can be recycled.

 Sort the individual components by type and dispose of them separately.

3.2 Saving energy

If you follow these instructions, your appliance will use less power.

Operate the appliance in a well-ventilated room and keep the ventilation opening on the appliance clear.

✓ If air exchange is impeded, this extends the programme duration and increases energy consumption.

Spin the laundry in the washing machine before drying.

 Damper laundry extends the programme duration and increases energy consumption.

Observe the programme's maximum load capacity.

- → "Programmes", Page 22
- If the maximum load is exceeded, this extends the programme duration and increases energy consumption.

After drying, clean the fluff filter → Page 27.

✓ If the fluff filter is dirty, this reduces the air flow in the appliance, extends the programme duration and increases energy consumption.

Dry the filters in the filter system of the base unit \rightarrow *Page 28* thoroughly after cleaning.

If the filters are damp, this extends the programme duration and increases energy consumption.

3.3 Energy saving mode

use the appliance again.

If you do not use the appliance for an extended period, it automatically switches to energy-saving mode. All displays go out and DIII flashes. Energy-saving mode ends when you use the appliance again, e.g. if you open or close the door. Energy-saving mode ends when you

4 Installation and connection

4.1 Unpacking the appliance

ATTENTION!

Objects remaining in the drum that are not designed for operation with the appliance may cause material damage and damage to the appliance.

- Remove these objects, along with all supplied accessories, from the drum before starting the appliance.
- Remove any packaging and protective covers completely from the appliance.
 - → "Disposing of packaging", Page 11
- 2. Check the appliance for visible damage.
- 3. Open the appliance door.

 → "Basic operation", Page 25
- **4.** Remove any accessories from the drum.
- 5. Close the appliance door.

4.2 Scope of delivery

After unpacking all parts, check for any damage in transit and completeness of the delivery.

ATTENTION!

If the appliance is operated with incomplete or defective accessories, the appliance may not be able to operate properly, or this may result in material damage or damage to the appliance.

 Do not operate the appliance with incomplete or defective accessories.

- Replace the accessories in question before operating the appliance.
 - → "Accessories", Page 24

Included with the appliance	Description
	Tumble dryer
	Accompanying documents

4.3 Requirements for the installation location

ATTENTION!

If the appliance is tilted at an angle greater than 40°, residual water may leak out of the appliance and cause material damage.

- ► Tilt the appliance carefully.
- ► Transport the appliance in an upright position.

If residual water in the appliance freezes, this may cause damage to the appliance.

 Do not install or operate this appliance anywhere that is liable to experience frost or outdoors.

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.


Installation loca- Requirements tion

On the floor



Place the appliance on a clean, level and firm surface.
Align the appliance
→ Page 14.

In a washer-dryer stack




Only use the original connection set from the dryer manufacturer when setting up this appliance in a washer-dryer stack.

→ "Accessories", Page 24

→ "Accessories". Page 24 This appliance must only be stacked on a washing machine from the same manufacturer. The depth and width of this appliance must correspond with the dimensions of the washing machine. Do not place the washer-dryer

Against a wall



Do not trap the hoses and power cord between the wall and the appliance.


stack on a plat-

form.

4.4 Aligning the appliance

In order to reduce vibrations and noises, align the appliance correctly.

► To align the appliance, turn the appliance feet. Check that the appliance is level using a spirit level.



All appliance feet must stand firmly on the ground.


4.5 Connecting the appliance to the electricity supply

- 1. Insert the mains plug of the appliance's power cable in a socket nearby.
 - The connection details of the appliance can be found under Technical data → Page 44.
- 2. Check the mains plug is inserted properly.

5 Familiarising yourself with your appliance

5.1 Appliance

You can find an overview of the parts of your appliance here.




On certain models, specific details such as the colour and shape may differ from those pictured.

- Ventilation opening
- Maintenance flap on the base unit → Page 33
- Fluff filter → Page 27

- Door
- Condensation container → Page 30
- Control panel → Page 16

5.2 Control panel

You can use the control panel to configure all functions of your appliance and to obtain information about the operating status.




- 1 Programmes → Page 22
- Programme selector

 → Page 25
- 3 Display → Page 17
- 4 Buttons → Page 19

6 Display

The display shows the current settings, options or relevant information.



Example: Display

Display	Designation	Description
0:40 1	Programme dura- tion/programme time remaining	Approximate expected programme duration or programme time remaining.
0:45	Timed programme	The timed programme is set. → "Timed programmes", Page 23
10h ¹	"Ready in" time	→ "Buttons", Page 20
	Childproof lock	 ■ lights up: The childproof lock is activated. ■ flashes: The childproof lock is activated and the appliance has been operated. → "Deactivating the childproof lock", Page 31
D00	Start/Pause	 Start, cancel or pause Lights up: The programme is running and can be cancelled or paused. Flashes: The programme can be started or continued.
次, 次, 次,	Dryness level adjusted	The adjusted dryness level is activated. → "Buttons", Page 19
Z	Crease-reduction function	The crease-reduction function is activated. → "Buttons", Page 19
W.	Gentle drying	Gentle drying is activated for delicate fabrics. → "Buttons", Page 19
¹ Example		

en Display

Display	Designation	Description
± in the second of the second	Condensation container	Empty the condensation container → Page 30. Insert the condensation container → Page 30.
œ́.	Fluff filter Filter system on the base unit	Clean the fluff filter → Page 27. Clean the filter system on the base unit → Page 28.
Hot	Cooling process	The laundry is cooled while the drum is rotating, in order to avoid damage to the laundry. The process can be cancelled by opening the door.
		Note: Do not change the programme.
<u> </u>	Drying	Programme status
	Dryness level: Iron Dry	Programme status
<u> </u>	Dryness level: Cupboard Dry	Programme status
1	Anti-crease	Programme status
⊳ 00	Pause	Programme status
End	End of pro- gramme	Programme status
¹ Example		

7 Buttons

Below is an overview of the buttons and their setting options.

Button	Selection	Description
▷ 00	StartCancelPause	Start, cancel or pause the programme.
∞ 3 sek.	ActivateDeactivate	Activate or deactivate the childproof lock. Disable the control panel to prevent unwanted or accidental operation. If the childproof lock is activated and the appliance has been switched off, the childproof lock remains activated. → "Childproof lock", Page 31
<u>*</u> ±	 ★¹ ★² ★³ 	Adjust the dryness level. If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level. → "Adjusting the dryness level", Page 21
2	ActivateDeactivate	Activate or deactivate the crease-reduction function. Once the programme has ended, the drum moves the laundry at regular intervals for 60 minutes to prevent creasing.
<i>₩</i>	ActivateDeactivate	Activate or deactivate gentle drying. The temperature is reduced for delicate fabrics, e.g. polyacrylic or elastane. The programme duration is extended.

en Buttons

Button	Selection	Description
©	Up to 24 hours	Set the programme end. The programme duration is already included in the set number of hours. Once the programme has started, the programme duration is displayed.
©	20 min - 3:30 h	Set the programme duration for timed programmes. → "Timed programmes", Page 23

8 Dryness level

Each automatic programme has a specified dryness level. The dryness level defines how dry or damp your laundry is after the programme ends.

Dryness level	Laundry	Drying result
Cupboard Dry Extra	Multi-layered, thick laundry that does not dry readily.	The laundry is dry.
Cupboar d Dry	Normal, single-layered laundry.	The laundry is dry.
Iron Dry	Normal, single-layered laundry	The laundry is still a little damp after drying. To prevent creasing after drying, iron the laundry or hang it up.

8.1 Changing the dryness level

For some automatic programmes, you can change the dryness level so that your laundry will be drier or more damp.

 Set an automatic programme with the desired dryness level. → "Automatic programmes", Page 22

8.2 Adjusting the dryness level

If the laundry feels too damp after it has been dried to a particular dryness level, you can adjust the dryness level.

- 1. Set an automatic programme with the desired dryness level.
 - → "Automatic programmes", Page 22
- 2. Press *: .
- ✓ The display shows: ※¹, ※² or ※³

21

9 Programmes

You can dry your fabrics using either an automatic programme or a timed programme.

9.1 Automatic programmes

Automatic programmes are programmes in which humidity sensors measure the residual moisture in the laundry during the drying cycle. The programme only ends once the set dryness level is reached. Each automatic programme has a dryness level → Page 21. The dryness level defines how dry or damp the laundry is after the programme ends.

Tips

- Select the dryness level according to the type of fabric or the desired drying result.
 - → "Dryness level", Page 21
- The laundry's care labels provide you with additional information about programme selection.

Programme	Description	Max. load (kg)
Cotton Cupboard Dry Extra Cupboard Dry Iron Dry	Dry hard-wearing, heat-resistant fabrics made of cotton or linen.	8,0
Easy Care Cupboard Dry Extra Cupboard Dry Iron Dry	Dry items made of synthetic materials or blended fabrics.	3.5
Mix	Dry items made of cotton and synthetics.	3.0
Down	 Dry clothing, bedspreads or eiderdowns stuffed with down. Notes Dry large items of laundry, such as blankets or sleeping bags individually. Once the programme has ended, shake 	1.5
Outdoor	the items of laundry to distribute the stuffing and eliminate any pockets of moisture. Dry weatherproof and outdoor clothing	1.5
	with a membrane coating and water-repellent fabrics.	

Programme	Description	Max. load (kg)
Shirts	Suitable for shirts and blouses made of cotton, linen, synthetics or blended fabrics. Note: For optimal drying results, dry a maximum of 5 shirts or 5 blouses at the same time. Once the laundry is dry, iron it or hang it up. The residual moisture is then distributed evenly.	1.5
Super 40'	Dry items made of synthetics and light cotton.	1.0
Towels	Dry hard-wearing, heat-resistant towels and dressing gowns made of cotton or linen.	6.0

9.2 Timed programmes

Timed programmes are programmes with a defined or adjustable programme duration. The programme ends once this time has elapsed, even if the laundry is still not dry, for example. Timed programmes are suitable for drying individual items of laundry or thin fabrics.

Tip: The laundry's care labels provide you with additional information about programme selection.

Timed program	Description	Max. load (kg)
Wool Finish	Dry machine-washable items made of wool or containing wool.	0.5
	Note: The laundry becomes fluffier but not dry. Remove laundry once the programme has ended and allow it to dry.	
Time Program Cold	Dry all types of fabric except for wool and silk. Also suitable for freshening up or airing clothing that has hardly been worn.	3.0
Time Program Warm	Dry all types of fabric except for wool and silk. Suitable for pre-dried or slightly damp laundry and for drying off multi-layered, thick laundry.	3.0

10 Accessories

Use original accessories. These have been made especially for your appliance.

Note: Some accessories are available in other colours. Contact → "Customer Service", Page 42.

	Use	Order number
Connection kit	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer.	WZ11410
Connection kit with pull- out worktop	To save space, stack the appliance on a suitable washing machine of the same width and depth and that is from the same manufacturer. The pull-out worktop makes it easier to load and unload the appliance.	WZ20400
Y-distributor	Connect the water drain hose of an additional appliance to the same siphon outlet.	15000490
Water drain hose	Drain away excess condensation directly into the waste water system, without having to regularly empty the condensation container.	WZ20160
Filter mat	Spare part to protect against fluff for the base unit's filter system.	12007650
Platform	Install the appliance at a raised height so that it can be easily loaded and unloaded.	WZDP20D

11 Laundry

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on siemens-home.bshgroup.com.

11.1 Preparing the laundry

ATTENTION!

Objects remaining in the laundry may damage the laundry and the drum.

- ► Remove all items from any pockets in your laundry before using the appliance.
- ▶ To protect your appliance and the laundry, prepare the laundry beforehand.
 - Empty any pockets
 - Brush sand out of all collars and pockets
 - Close bed covers and cushion covers
 - Close all zips, Velcro fasteners, hooks and eyes
 - Tie cloth belts, apron strings, etc. together or use a laundry
 - Remove curtain hooks and lead strips or use a mesh laundry bag
 - Use a mesh laundry bag for small items of laundry, such as children's socks
 - Separate items of laundry and shake them out, or observe the programme description
 - Spin the laundry before drying

12 Basic operation

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on siemens-home.bshgroup.com.

12.1 Switching on the appliance

Requirement: The appliance has been correctly installed and connected.

- → "Installation and connection", Page 12
- Turn the programme selector to a programme.

12.2 Setting a programme

- 1. Turn the programme selector and set the required programme.
 - → "Programmes", Page 22
- 2. If required, adjust the programme settinas.
 - → "Adjusting the programme settings", Page 25

12.3 Adjusting the programme settings

Depending on the programme and programme progress, you can adjust or activate/deactivate the settings.

Requirement: A programme is set. → "Setting a programme", Page 25

Adjust the programme settings. → "Buttons", Page 19

Note: The programme settings are not saved permanently for the programme.

12.4 Loading laundry

Note: To prevent creasing, note the maximum load for the programmes. → "Programmes", Page 22

Requirement: The laundry is prepared.

- → "Laundry", Page 25
- Open the door.
 Ensure that the drum is empty.
- 2. Place the laundry in the drum.
- Close the door.Ensure that there is no laundry trapped in the door.

12.5 Starting the programme

Requirement: A programme is set. → "Setting a programme", Page 25

- ▶ Press ▷□.
- ▼ The display shows the programme duration or the "Ready in" time.
- ✓ After the programme has ended, the display shows: "End" .

Note: If "Hot" appears, the appliance cools the laundry. When "Hot" goes out, the laundry has cooled down.

12.6 Changing the activated "Ready in" time

If you have set and activated a "Ready in" time for a delayed programme start, you can change the "Ready in" time again before the programme starts.

Requirements

- The programme is set.
 - → "Setting a programme", Page 25
- The "Ready in" time is set and activated.
 - → "Buttons", Page 20
- 1. Press ▷□.

- The activated "Ready in" time is paused.
- Press repeatedly until the display indicates the desired "Ready in" time.
- 3. Press ▷□.

The changed "Ready in" time is activated.

12.7 Adding laundry

After the programme starts, you can remove or add laundry at any time.

Requirement: A programme has started.

- → "Starting the programme", Page 26
- 1. Press ▷□.

The cooling process starts automatically after approximately 30 seconds and cools down the laundry while the drum is rotating. If you want to avoid or cancel the cooling process, open the door.

→ "Display", Page 18

- 2. Open the door.
- 3. Add or remove laundry.
- 4. Close the door.
- 5. Press ▷II.

12.8 Cancelling the programme

- 1. Press ▷□.
- 2. Open the appliance door.
- Remove the laundry.
 → "Unloading the laundry",
 Page 26

12.9 Unloading the laundry

- 1. Open the door.
- 2. Remove the laundry from the drum.

12.10 Switching off the appliance

► Turn the programme selector to Off O.

12.11 Fluff filter

During drying, fluff from the laundry is collected in the fluff filter. The fluff filter protects the appliance from fluff.


Cleaning the fluff filter

If the drying programme has finished or the display shows a notification while the appliance is in operation, clean the fluff filter.


Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

Requirements


- The display shows the following after drying: "End"
- or during operation:
- 1. Open the door.
- 2. Remove the fluff from the door.



3. Remove the two-part fluff filter.




4. Remove the fluff from the recess.




Ensure that no fluff falls into the air channel.


5. Disconnect the two-part fluff filter.




6. Open the two fluff filters.




7. Remove the fluff.




8. Clean the two fluff filters thoroughly under warm, running water and then dry them off.



9. Close the two fluff filters and put them together.



10. Insert the two-part fluff filter.



11. Close the door.

12.12 Filter system on the base unit

During drying, fluff from the laundry is collected in the base unit's filter system. The filter system protects the appliance from fluff.

Cleaning the filter system on the base unit


If the display shows a notification while the appliance is in operation, clean the base unit's filter system.

Notes

You can clean the filter regularly system even without the notification being shown on the display. It is not necessary to clean after each drying cycle. If you do not clean the appliance as described, the appliance's functionality may be impaired.


Requirement: The display shows the

- 1. Clean the fluff filter → Page 27.
- **2.** Open the base unit \rightarrow Page 33.
- 3. Carefully remove the filter mat from the retainers.




Ensure that you do not deform or damage the filter mat.

4. Use a soft brush to clean the heat exchanger cover.




Make sure that you remove all dirt from the seal.

5. Clean the filter mat thoroughly under warm, running water and squeeze it out by hand.



You can remove heavy soiling carefully using a vacuum cleaner. Do not clean the filter mat using cleaning products.

6. Push the filter mat onto the retainers.



Ensure that the cleaned filter mat is not deformed, damaged or inverted when you push it onto the retainers.

Note: You can order the filter mat → Page 24 as a spare part from customer service.

7. Close the base unit \rightarrow Page 35.

12.13 Condensation container


Condensation forms during drying, which your appliance uses for automatic cleaning. By default, the condensation is collected in the appliance's condensation container.

Emptying the condensation container


If the drying programme has finished or the display shows a notification while the appliance is in operation, empty the condensation container.

Requirements

- The display shows the following after drying: "End"
- or during operation: 🖺 .
- **1.** Pull out the condensation container, keeping it level.



2. Empty the condensation container.




Make sure that you insert the condensation container before operating the appliance.

→ "Inserting the condensation container", Page 30

Inserting the condensation container

Requirement: The condensation container \rightarrow *Page 30* is removed from the appliance.

 Push the condensation container in as far as it will go.



13 Childproof lock

Secure your appliance against being operated unintentionally using the controls.

13.1 Activating the childproof lock

- ▶ Press and hold the two 🖘 3 sek. buttons for approx. 3 seconds.
- The controls are locked.
- The childproof lock remains active even after the appliance has been switched off and in the event of a power failure.

13.2 Deactivating the childproof lock


Requirement: To deactivate the childproof lock, the appliance must be switched on.

- ▶ Press and hold the two 🖘 3 sek. buttons for approx. 3 seconds.
- ✓ so goes out in the display.

14 Basic settings

You can configure the basic settings for your appliance to meet your needs.


14.1 Overview of the basic settings



Basic setting	Programme position	Value	Description
End signal	3	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	Set the volume of the signal at the end of the programme.
Button signal	4	0 (off) 1 (quiet) 2 (me- dium) 3 (loud) 4 (very loud)	The volume of the audible signal emitted when the buttons are pressed.
Washing ma- chine spin speed	2	Example: 600 (low) 1800 (high)	Set the spin speed of the washing machine. The set value increases or decreases the displayed duration of the automatic programmes.

14.2 Changing the basic settings

1. Set the programme selector to position 1.



- 2. Press ▷ and, at the same time, turn the programme selector to position 2.
- ▼ The display shows the current value.
- 3. Set the programme selector to the required position.
- 4. To change the value, press 9 /
- 5. To save the changes, switch off the appliance.

15 Cleaning and servicing

To keep your appliance working efficiently for a long time, it is important to clean and maintain it carefully.

Note: You can find further information in the digital instruction manual by scanning the QR code in the table of contents or on siemens-home.bshgroup.com.

15.1 Tips on cleaning and care

Wipe down the housing and the controls with nothing but water and a damp cloth.	This ensures the parts of the appliance will remain clean and hygienic.
Remove all detergent residue, spray residue or other residues immediately.	Fresh deposits are easier to re- move without leaving any residue.
Leave the appliance door open after use.	This allows the residual water to dry, reducing odours in the appliance.

15.2 Base unit


The base unit is the accessible area. at the bottom of the appliance in which you will find the heat exchanger.

Opening the base unit Requirements

- The appliance has cooled down for 30 minutes.
- The appliance door is closed.


en Cleaning and servicing

1. Open the maintenance flap.




If you place a cloth beneath the maintenance flap, you can collect the remaining water from the base unit.

2. Open the lever for the heat exchanger cover.



3. Pull out the heat exchanger cover by the handle.




Cleaning the base unit

You can remove any visible dirt in the base unit.

⚠ CAUTION Risk of cutting!


Touching sharp edges on the heat exchanger may lead to cuts.

- ▶ Do not touch the fins on the heat exchanger.
- **1.** Open the base unit \rightarrow Page 33.
- **2.** Use a soft brush to clean the heat exchanger cover.




Make sure that you remove all dirt from the seal.

Carefully clean the fins on the heat exchanger with a vacuum cleaner and brush attachment.



Ensure that you vacuum the fins from top to bottom so that they do not become deformed or damaged.

4. Clean the opening with a soft, damp cloth.




5. Close the base unit \rightarrow Page 35.


Closing the base unit

Requirement: The base unit is open. → "Opening the base unit", Page 33


1. Insert the heat exchanger cover by the handle



2. Close the lever for the heat exchanger.



3. Close the maintenance flap.



15.3 Moisture sensor

The moisture sensor in this appliance measures how damp the laundry is during the drying cycle. The appliance changes the duration of the automatic programme depending on the residual moisture in the laundry.

Cleaning the moisture sensor

Over time, residue from limescale, detergents and care products can build up on the moisture sensor. Clean the moisture sensor regularly.

ATTENTION!

Hard or rough objects may damage the moisture sensor.

► Do not use hard or rough objects, abrasive cleaning products or steel wool for cleaning.

Note: If you do not clean the appliance as described, the appliance's functionality may be impaired.

1. Open the door.

- en Cleaning and servicing
- **2.** Clean the moisture sensor with a sponge.



16 Troubleshooting

You can rectify minor faults on your appliance yourself. Read the troubleshooting information before contacting after-sales service. This will avoid unnecessary costs.



⚠ WARNING

Risk of electric shock!

Incorrect repairs are dangerous.

- ► Repairs to the appliance should only be carried out by trained specialist staff.
- ► Only use genuine spare parts when repairing the appliance.
- ► If the power cord of this appliance is damaged, it must be replaced by the manufacturer, the manufacturer's Customer Service or a similarly qualified person in order to prevent any risk.

Fault	Cause and troubleshooting			
"Hot" and the drum rotates.	Cooling process active. 1. Not a fault. 2. Do not change the programme during the cooling process.			
	Note: The cooling process takes up to 10 minutes. You can continue to operate the appliance.			
Humming noise.	Compressor active. Not a fault – normal operating noise.			
The display goes out and ▷□ flashes.	Energy-saving mode is active Press any button.✓ The symbol lights up again.			
	Fluff filter is soiled. ▶ → "Cleaning the fluff filter", Page 27			
	The base unit's filter is soiled. ► → "Cleaning the filter system on the base unit", Page 28			
The appliance is not working.	The mains plug of the power cord is not plugged in. Connect the appliance to the power supply.			
	The circuit breaker in the fuse box has tripped. • Check the circuit breaker in the fuse box.			
	There has been a power cut. ► Check whether the lighting in your kitchen or other appliances are working.			
Appliance paused, but the drum is rotating.	Cooling process active. Not a fault – no action required.			

Fault	Cause and troubleshooting				
Creasing.	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 22.				
	The laundry lies in the drum for too long after drying.1. Remove the laundry from the drum as soon as the drying programme has finished.2. Spread the items of laundry for cooling.				
	Unsuitable programme for the type of fabric. ► Set the suitable programme for the type of fabric. → "Programmes", Page 22				
	Easy-Care fabrics are dried for too long. ► → "Changing the dryness level", Page 21. ► → "Adjusting the dryness level", Page 21.				
	Anti-Crease not activated. ► Activate the Anti-Crease function. → "Buttons", Page 19				
and programme terminated.	 Condensation tank filled. 1. → "Emptying the condensation container", Page 30. 2. → "Inserting the condensation container", Page 30. 3. → "Starting the programme", Page 26. 				
	Water drain hose is caught or jammed.1. Ensure that the water drain hose is not kinked or trapped.2. Route the water drain hose without kinks.				
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly.				
	Water drain hose is blocked. ► Rinse the water drain hose with tap water.				
	Foreign object is located in the base unit 1. → "Opening the base unit", Page 33. 2. Remove the foreign objects that are present. 3. → "Closing the base unit", Page 35.				
Condensation in the condensation tank even though the water drain hose is connected.	The appliance uses condensation for the automatic self-cleaning. Not a fault – no action required.				
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly.				

Fault	Cause and troubleshooting			
The programme does not start.	Childproof lock is activated. → "Deactivating the childproof lock", Page 31			
	You have not pressed ▷□. ▶ Press ▷□.			
	No programme set. 1. → "Setting a programme", Page 25. 2. → "Starting the programme", Page 26.			
The length of the programme changes during the drying cycle.	The programme operation is optimised electronically. This may change the programme duration. Not a fault – no action required.			
Pumping noise.	Condensation pump active. ► Not a fault – normal operating noise.			
Buzzing noise.	Compressor ventilation active. Not a fault – normal operating noise.			
The drying time is too long.	The base unit's filter is soiled. ► → "Cleaning the filter system on the base unit", Page 28			
	Fluff filter is soiled. ► → "Cleaning the fluff filter", Page 27			
	The ambient temperature is greater than 30 °C. ► Ensure that the ambient temperature is lower than 30 °C.			
	The ambient temperature is lower than 15 °C. ► Ensure that the ambient temperature is above 15 °C.			
	Insufficient air circulation at the appliance's installation location. • Ventilate the appliance's installation location.			
	The appliance's ventilation opening is blocked. ► Ensure that the air inlet on the appliance is kept clear.			
	Heat exchanger is soiled. 1. → "Opening the base unit", Page 33. 2. Clean the heat exchanger. → "Cleaning the base unit", Page 34. 3. → "Closing the base unit", Page 35.			
Water is leaking from the appliance.	Appliance is not correctly aligned. ► → "Aligning the appliance", Page 14 The seal for the best explanger cover is dirty.			
	The seal for the heat exchanger cover is dirty.			

en froubleshooting					
Fault	Cause and troubleshooting				
Water is leaking from the appliance.	Clean the seal for the heat exchanger cover. → "Cleaning the filter system on the base unit", Page 28				
	Water drain hose is not connected correctly. ► Ensure that the water drain hose is connected correctly.				
	 The lever for the heat exchanger cover is not closed correctly. ► Ensure that the lever for the heat exchanger cover is closed correctly. → "Closing the base unit", Page 35 				
The laundry is too damp.	Unsuitable programme for the type of fabric. ► Set a timed programme for the subsequent drying. → "Programmes", Page 22				
	There has been a power cut. ► Check whether the lighting in your kitchen or other appliances are working.				
	The load is too large. ► Observe the maximum load capacity of the → "Programmes", Page 22.				
	 After the end of the programme, warm laundry feels damper than it actually is. 1. Remove the laundry from the drum as soon as the drying programme has finished. 2. Spread the items of laundry for cooling. 				
	Unsuitable dryness level set. ► → "Changing the dryness level", Page 21.				
	Drying target not adjusted. ► → "Adjusting the dryness level", Page 21.				
	Load too small. ► Set a timed programme for the subsequent drying. → "Programmes", Page 22				
	Moisture sensor dirty. ► → "Cleaning the moisture sensor", Page 35.				
	The drying process is interrupted and the condensation tank has been filled. 1. → "Emptying the condensation container", Page 30. 2. → "Inserting the condensation container", Page 30. 3. → "Starting the programme", Page 26.				

17 Transportation, storage and disposal

17.1 Preparing the appliance for transportation

ATTENTION!

If the appliance is operated immediately after transportation, the refrigerant contained in the appliance may result in damage to the appliance.

► Immediately after transporting the appliance, leave it to rest for two hours before putting it into operation.

Tip: The appliance may contain residual water, which may drip out of it when transported. The appliance should be transported upright.

Requirements

- The condensation container is emptied. Emptying the condensation container → Page 30
- The appliance has been switched
 - → "Switching on the appliance", Page 25
- **1.** Set any programme \rightarrow *Page 25*.
- 2. Start the programme → Page 26 and wait 5 minutes.
- The condensation is drained.
- **3.** Switch off the appliance. → "Switching off the appliance", Page 27
- 4. Remove the water drain hose from the connection point.
- 5. Secure the water drain hose on the appliance against unintentional loosening.
 - Ensure that you do not bend the water drain hose.
- 6. Empty the condensation container → Page 30.

- 7. Insert the condensation container → Page 30.
- 8. Disconnect the appliance's mains plug from the power supply.
- ▼ The appliance is now ready to be transported.

17.2 Disposing of old appliance

Valuable raw materials can be reused by recycling.

⚠ WARNING Risk of harm to health!

Children can lock themselves in the appliance, thereby putting their lives at risk.

- Do not install the appliance behind a door as this may obstruct the appliance door or prevent it from opening.
- With redundant appliances, unplug the power cord. Then cut through the cord and damage the lock on the appliance door beyond repair so that the appliance door will no longer close.

⚠ WARNING Risk of fire!

The refrigerant R290 used in this appliance is environmentally friendly. It is however flammable and may ignite if appliances are not disposed of properly.

- Dispose of the appliance properly.
- Do not damage the tubing of the refrigerant circuit.
- 1. Unplug the appliance from the mains.
- 2. Cut through the power cord.
- 3. Dispose of the appliance in an environmentally friendly manner.

Information about current disposal methods are available from your specialist dealer or local authority.



This appliance is labelled in accordance with European Directive 2012/19/EU concerning used electrical and electronic appliances (waste electrical and electronic equipment - WEEE). The guideline determines the framework for the return and recycling of used appliances as applicable throughout the EU.

18.1 Product number (E-Nr.) and production number (FD)

You can find the product number (E-Nr.) and the production number (FD) on the appliance's rating plate. Depending on the model, the rating plate is located:

- On the inside of the door.
- On the inside of the maintenance flap.
- On the rear of the appliance.

Make a note of your appliance's details and the Customer Service telephone number to find them again quickly.

18 Customer Service

Function-relevant genuine spare parts according to the corresponding Ecodesign Order can be obtained from Customer Service for a period of at least 10 years from the date on which your appliance was placed on the market within the European Economic Area.

Note: Under the terms of the manufacturer's warranty the use of Customer Service is free of charge.

Detailed information on the warranty period and terms of warranty in your country is available from our aftersales service, your retailer or on our website.

If you contact Customer Service, you will require the product number (E-Nr.) and the production number (FD) of your appliance.

The contact details for Customer Service can be found in the enclosed Customer Service directory or on our website.

19 Consumption values

The programme

Cotton Cupboard Dry

(denoted by the arrow symbol) is suitable for drying cotton laundry with a normal dampness level, and is the most efficient programme for drying damp cotton laundry in terms of combined energy consumption.

The consumption values for this programme that are declared on the energy label refer to a moisture content of the laundry of 60%.

The values given for other programmes are indicative only and were determined in accordance with the applicable standard EN61121.

The actual values may deviate from the indicated values depending on the type of fabric, composition of laundry to be dried, residual moisture in the fabric, set degree of dryness, amount of laundry being loaded, environmental conditions and the activation of additional functions. The expected programme dura-

tion/"Ready in" time that is shown on the appliance display when selecting the programme is based on the spin speed in the washing machine of 1000 rpm when the appliance is delivered.

Programme	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Cotton Cupboard Dry	0,0	8,0	1400	50	3:01	1,63
Cotton Cupboard Dry	0,0	4,0	1400	50	1:56	1,00
Cotton Cupboard Dry	0,0	8,0	1000	60	3:25	1,87
Cotton Cupboard Dry	0,0	4,0	1000	60	2:10	1,14
Cotton Cupboard Dry	0,0	8,0	800	70	3:50	2,11
Cotton Cupboard Dry	0,0	4,0	800	70	2:25	1,28
Cotton Iron Dry	12,0	8,0	1400	50	2:16	1,21
Cotton Iron Dry	12,0	4,0	1400	50	1:23	0,70
Cotton Iron Dry	12,0	8,0	1000	60	2:40	1,45
Cotton Iron Dry	12,0	4,0	1000	60	1:37	0,84
Cotton Iron Dry	12,0	8,0	800	70	3:05	1,69
Cotton Iron Dry	12,0	4,0	800	70	1:52	0,98

Programmo	Э	Final mois- ture level (%)	Load (kg)	Spin speed (rpm)	Initial mois- ture level (%)	Pro- gramm e dura- tion (h:min)	Energy con- sump- tion (kWh/ cycle)
Easy Care board Dry	Cup-	2,0	3,5	800	40	1:12	0,60
Easy Care board Dry	Cup-	2,0	3,5	600	50	1:24	0,71

20 Technica	l data
Appliance height	84,2 cm
Appliance width	59,8 cm
Appliance depth	61,3 cm
Appliance depth with door closed	65,1 cm
Appliance depth with door open	110.5 cm
Weight	48,3 kg
Maximum load	8,0 kg
Mains voltage	220-240 V, 50 Hz
■ Minimum installation protection	10A
Nominal power	625 W
Power consumption	Off mode: 0,10 WLeft-on mode: 0,75 W
Ambient temperature	Minimum:5 °CMaximum:35 °C
Length of the power cord	145 cm

You can find more information about your model online at https://eprel.ec.europa.eu/1. This web address is linked to the official EU EPREL product database. Please then follow the instructions on searching for the model. The model identifier is made up of the characters before the slash in the product number (E-Nr.) on the rating plate. Alternatively, you can also find the model identifier in the first line of the EU energy label.

¹ Only applies to countries in the European Economic Area









BSH Hausgeräte GmbH

Carl-Wery-Straße 34 81739 München, GERMANY siemens-home.bsh-group.com

Valid within Great Britain: Imported to Great Britain by BSH Home Appliances Ltd. Grand Union House Old Wolverton Road Wolverton, Milton Keynes MK12 5PT United Kingdom

Manufactured by BSH Hausgeräte GmbH under the trademark licence of Siemens AG



en