



EN User Manual | Washer Dryer



EWI7H2E94E



## Welcome to Electrolux! Thank you for choosing our appliance.



Get usage advice, brochures, trouble shooter, service and repair information: www.electrolux.com/support

Subject to change without notice.

## CONTENTS

1. SAFETY INFORMATION	
2. SAFETY INSTRUCTIONS	
3. PRODUCT DESCRIPTION	7
4. TECHNICAL DATA	9
5. INSTALLATION	9
6. CONTROL PANEL	13
7. DIAL AND BUTTONS	15
8. SETTINGS	
9. BEFORE FIRST USE	19
10. PROGRAMMES	
11. DAILY USE - WASHING ONLY	
12. DAILY USE - WASHING & DRYING	32
13. DAILY USE - DRYING ONLY	33
14. FLUFF IN THE FABRICS	
15. HINTS AND TIPS	35
16. CARE AND CLEANING	38
17. TROUBLESHOOTING	43
18. CONSUMPTION VALUES	47
19. ENVIRONMENTAL CONCERNS.	

# **1. A SAFETY INFORMATION**

Before beginning the installation and use of this appliance, carefully read the supplied instructions. The manufacturer is not responsible for any injuries or damage that are the result of incorrect installation or usage. Always keep the instructions in a safe and accessible location for future reference.

# 1.1 Children and vulnerable people safety

## A WARNING!

Risk of suffocation, injury or permanent disability.

- This appliance can be used by children aged from 8 years and above and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the appliance in a safe way and understand the hazards involved.
- Children between 3 and 8 years of age and persons with very extensive and complex disabilities shall be kept away from the appliance unless continuously supervised.
- Children of less than 3 years of age should be kept away from the appliance unless continuously supervised.
- Children should be supervised to ensure that they do not play with the appliance.
- Keep all packaging away from children and dispose of it appropriately.
- Keep detergents away from children.
- Keep children and pets away from the appliance when the door is open.
- If the appliance has a child safety device, it should be activated.
- Children shall not carry out cleaning and user maintenance of the appliance without supervision.

# 1.2 General Safety

- This appliance is for washing and drying domestic-type machine-washable and dryable laundry only.
- Do not use the dryer function if laundry has been soiled with industrial chemicals.
- This appliance is designed for single household domestic use in an indoor environment.
- This appliance may be used in, offices, hotel guest rooms, bed & breakfast guest rooms, farm guest houses and other similar accommodation where such use does not exceed (average) domestic usage levels.
- Do not change the specification of this appliance.

- The appliance shall be installed as a freestanding product or below the kitchen worktop if space margins permit.
- Do not install the appliance behind a lockable door, a sliding door or a door with a hinge on the opposite side, that would prevent the appliance door from being fully open.
- Connect the mains plug to the mains socket only at the end of the installation process. Make sure that the mains plug is accessible after installation.
- The ventilation opening in the base must not be covered by a carpet, mat, or any floor covering.
- WARNING: The appliance must not be supplied through an external switching device, such as a timer, or connected to a circuit that is regularly switched on and off by a utility.
- Ensure good air ventilation in the room where the appliance is installed to avoid the backflow of unwanted gases into the room from appliances burning gas or other fuels, including open fires.
- Exhaust air must not be discharged into a flue which is used for exhausting fumes from any appliances burning gas or other fuels.
- The operating water pressure at the water entry point from the outlet connection must be between 0.5 bar (0.05 MPa) and 10 bar (1.0 MPa).
- The appliance maximum load is 9.0 kg. Do not exceed the maximum load of each programme (refer to the "Programmes" chapter).
- The appliance must be connected to the water mains using the new supplied hose sets, or other new hose sets supplied by the Authorised Service Centre.
- Old hose sets must not be reused.
- If the mains power supply cable is damaged, it must be replaced by the manufacturer, its Authorised Service Centre or similarly qualified persons to avoid an electrical hazard.
- Wipe away lint or packaging debris that has accumulated around the appliance.

- Items that have been soiled with substances such as vegetable or mineral oil, acetone, alcohol, petrol, kerosene, spot removers, turpentine, waxes and wax removers should be washed separately with an extra amount of detergent before being dried in the washer dryer.
- Do not use the appliance if items have been soiled with industrial chemicals.
- · Do not dry unwashed items in the wash dryer.
- Items such as foam rubber (latex foam), shower caps, waterproof textiles, and rubber backed articles and clothes, or pillows fitted with foam rubber pads should not be dried in the washer dryer.
- Fabric softeners, or similar products, should only be used as specified by the product manufacturer's instructions.
- Remove all objects from items that could be a source of fire ignition such as lighters or matches.
- WARNING: Never stop the washer dryer before the end of the drying cycle unless all items are quickly removed and separated so that residual heat can dissipate.
- The final part of the washer dryer cycle takes place without heat (cool down cycle) to ensure that items reach a temperature that will not cause damage to them.
- Do not use high pressure water sprays and/or steam to clean the appliance.
- Clean the appliance with a moist cloth. Use only neutral detergents. Do not use abrasive products, abrasive cleaning pads, solvents or metal objects.
- Before any maintenance operation, deactivate the appliance and disconnect the mains plug from the socket.

# **2.** SAFETY INSTRUCTIONS

## 2.1 Installation

i

The installation must comply with relevant national regulations.

- Follow the installation instructions supplied with the appliance.
- Do not install or use the appliance where the temperature can be less than 0°C or where it is exposed to the weather.
- Always keep the appliance vertical when it is being moved.

- Make sure that there is air circulation between the appliance and the floor.
- Remove all the packaging and the transit bolts.
- The floor area on which the appliance is to be installed must be flat, stable, heat resistant and clean.
- Keep the transit bolts in a safe place. If the appliance is to be moved in the future they must be reattached to lock the drum to prevent an internal damage.
- Always take care when moving the appliance as it is heavy. Always use safety gloves and enclosed footwear.
- Do not install or use a damaged appliance.
- Do not install the appliance where the appliance door cannot be fully opened.
- Adjust the feet to have the necessary space between the appliance and the flooring.
- When the appliance is in its permanent position, check if it is levelled correctly with the aid of a spirit level. If it is not, adjust the feet accordingly.

## **2.2 Electrical Connection**

### MARNING!

Risk of fire and electric shock.

- WARNING: This appliance is designed to be installed / connected to a grounding connection in the building.
- Always use a correctly installed shockproof socket.
- Do not use multi-plug adapters and extension cables.
- Do not pull the mains cable to disconnect the appliance. Always pull the mains plug.
- Do not touch the mains cable or the mains plug with wet hands.

## 2.3 Water Connection

- The inlet water shall not exceed 25 °C.
- Do not cause damage to the water hoses.
- Before connection to new pipes, pipes not used for a long time, where repair work has been carried out or new devices fitted (water meters, etc.), let the water flow until it is clean and clear.

- Ensure that there are no visible water leaks during and after the first use of the appliance.
- Do not use an extension hose if the inlet hose is too short. Contact the Authorised Service Centre for the replacement of the inlet hose.
- When unpacking the appliance, It is possible to see water flowing from the drain hose. This is due to the testing of the appliance with the use of water in the factory.
- You can extend the drain hose to maximum 400 cm. Contact the Authorised Service Centre for the other drain hose and the extension.
- Make sure that there is access to the tap after the installation.

## 2.4 Use

### 

Risk of injury, electric shock, fire, burns or damage to the appliance.

- Do not put flammable products or items that are wet with flammable products in, near or on the appliance.
- Do not touch the glass door while a programme operates. The glass can get hot.
- Do not dry damaged (torn, frayed) items that contain padding or fillings.
- If laundry has been washed with a stain remover, carry out an additional rinse cycle before starting a drying cycle.
- Make sure that all metal objects are removed from the laundry.
- Dry only fabrics that are suitable to dry in the appliance. Follow the cleaning instruction on the item label.
- Do not sit or stand on the open door of the appliance.
- Do not dry dripping wet clothes in the appliance.
- Do not let hot items to touch the plastic parts of the appliance.
- Remove a detergent ball (if used) before starting a drying programme.
- Do not use a detergent ball if setting a non-stop programme.

## 2.5 Service

- To repair the appliance contact the Authorised Service Centre. Use original spare parts only.
- Please note that self-repair or nonprofessional repair can have safety consequences and might void the guarantee.
- The following spare parts are available for at least 10 years after the model has been discontinued: motor and motor brushes. transmission between motor and drum. pumps, shock absorbers and springs, washing drum, drum spider and related ball bearings, heaters and heating elements, including heat pumps, piping and related equipment including hoses, valves, filters and aquastops, printed circuit boards. electronic displays. pressure switches, thermostats and sensors, software and firmware including reset software, door, door hinge and seals, other seals, door locking assembly, plastic peripherals such as detergent dispensers. The duration may be longer in your country. For further information, please visit our website.
- Please note that some of these spare parts are only available to professional

# **3.** PRODUCT DESCRIPTION

## 3.1 Special features

Your new washer-dryer meets all modern requirements for effective treatment of laundry with low water, energy and detergent consumption and proper care of fabric.

 SteamCare system, thanks to Steam Refresh steam programme, offers the perfect solution for refreshing even the most delicate garments without washing. Use the delicate fragrance exclusively developed by Electrolux to add a repairers, and that not all spare parts are relevant for all models.

• Concerning the lamp(s) inside this product and spare part lamps sold separately: These lamps are intended to withstand extreme physical conditions in household appliances, such as temperature, vibration, humidity, or are intended to signal information about the operational status of the appliance. They are not intended to be used in other applications and are not suitable for household room illumination.


## 2.6 Disposal

- Disconnect the appliance from the mains electrical and water supplies.
- Cut off the mains electrical cable close to the appliance and dispose of it.
- Remove the door catch to prevent children or pets from becoming trapped in the drum.
- Dispose of the appliance in accordance with local requirements for the disposal of Waste Electrical and Electronic Equipment (WEEE).

pleasant feeling of "just-washed" garment to the removing odours and wrinkles action.

 The SensiCare System detects the laundry load size defining the programme duration in 30 seconds. The washing programme is tailored to the laundry load and the type of fabric without consuming more time, energy and water than necessary.

## 3.2 Appliance overview



Scan the **QR code** on the appliance to register your product and get the most out of it.

- LL Access your appliance details, documentation and articles on how to use the best features (User Manual also available at electrolux.com/manuals)
- Get usage advice, troubleshooting, service and repair information (also available at electrolux.com/ support )
- Buy accessories, Consumable and Original Spare parts for you appliance (also available at electrolux.com/shop)

# 4. TECHNICAL DATA

Dimension	Width/ Height/ Total depth	59.7 cm /84.7 cm /57.6 cm	
Electrical connection	Voltage	230 V	
	Overall power	2100 W	
	Fuse	10 A	
	Frequency	50 Hz	
	ngress of solid particles and moisture over, except where the low voltage n against moisture	IPX4	
Water supply 1)		Cold water	
	Minimum	Cold water 0.5 bar (0.05 MPa)	
	Minimum Maximum		
		0.5 bar (0.05 MPa)	
Water supply <b>1)</b> Water supply pressure Maximum wash load Maximum dry load	Maximum	0.5 bar (0.05 MPa) 10 bar (1.0 MPa)	
Water supply pressure Maximum wash load	Maximum Cotton	0.5 bar (0.05 MPa) 10 bar (1.0 MPa) 9.0 kg	

1) Connect the water inlet hose to a water tap with a 3/4" thread.

# **5. INSTALLATION**

## 

Refer to Safety chapters.

## 5.1 Unpacking

**1.** Open the door. Remove all the items from the drum.




## $(\mathbf{i})$

Accessories delivered with the appliance may vary depending on the model.

2. Put the packaging element on the floor behind the appliance and carefully put it


down onto its rear side. Remove the polystyrene protection from the bottom.



## 

Do not lay washing machine on its front.


3. Put the appliance back into an upright position. Remove the power supply cable and the drain hose from the hose holders.



## $(\mathbf{i})$

It is possible to see water flowing from the drain hose. This is because the washing machine has been tested at the factory.


 Remove the three transit bolts and pull out the plastic spacers.



## $(\mathbf{i})$

We recommend that you keep the packaging and the transit bolts for any transport of the appliance.

5. Put the plastic caps, that you find in the user manual bag, in the holes.



5.2 Information for installation Positioning and levelling

Adjust the appliance correctly to prevent vibration, noise and movement of the appliance when it operates.

1. Install the appliance on a flat hard floor. The appliance must be levelled and stable. Make sure that the appliance does not touch the wall or other units and there is air circulation below the appliance.

2. Loosen or tighten the feet to adjust the level. All feet must rest firmly on the floor.

## ⚠ WARNING!


Do not put cardboard, wood or equivalent materials below the appliance feet to adjust the level.

#### The inlet hose

## ⚠́ CAUTION!


Make sure there is no damage to hoses and there are no leaks from the couplings. Do not use an extension hose if the inlet hose is too short. Contact the service centre for information on inlet hose replacement.

1. Connect the water inlet hose to the back of the appliance if needs. Usually, it is already installed at the factory.



- 2. Position it toward left or right depending on the positon of the water tap. Make sure that the inlet hose is not in vertical position.
- **3.** If necessary, loosen the ring nut to set it in the correct position.
- Some model can contain inlet hose with water stop device. It prevents any leaks in

the hose because of its natural ageing. The sector in the window shows this fault A. If this occurs, close the water tap and contact the authorized service center for information to replace the hose.



 Connect the other end of the COLD water inlet hose to the cold water tap with 3/4" thread.

#### 

The inlet water shall not exceed 25 °C.


#### Water drainage

The drain hose should stay at a height of no less than 60 cm and not more than 100 cm.

i

You can extend the drain hose to maximum 400 cm. Contact the authorised service centre to buy the other drain hose and the extension.

It is possible to connect the drain hose in different ways:



\* Subject to change spare parts without notice.

Make sure that the drain hose makes a loop to prevent particles going into the appliance from the sink.

Connect the drain hose to the spigot and tighten it with a clamp. Make sure that the drain hose makes a loop to prevent particles going into the appliance from the sink.

Position the hose directly to a built-in drain pipe in the room wall and tighten it with a clamp.

Without the plastic hose guide, to a sink spigot- Put the drain hose in the spigot and tighten it with a clamp.

The drain hose can be bent into U shape and put around the plastic guide. On the edge of a sink - Fasten the guide to the water tap or to the wall.

 $(\mathbf{i})$ 

Make sure that the plastic guide cannot move when the appliance drains and the drain hose end is not immersed in the water. There may be a return of dirty water into the appliance. Buy accessories from authorised supplier.

To a stand pipe with vent hole - Insert the drain hose directly into a drain pipe or stand pipe

 $(\mathbf{i})$ 

The end of the drain hose must always be ventilated , i.e. the inner diameter of the drain pipe (min. 38 mm - min. 1.5") must be larger than the external diameter of the drain hose.

## 5.3 Electrical connection


At the end of installation you can connect the mains plug to the mains socket.

The rating plate and the 'Technical Data' chapter indicate the necessary electrical

ratings. Make sure that they are compatible with the mains power supply.

Check that your domestic electrical installation can take the maximum load required, also taking into account any other appliances may also be in use.

# Connect the appliance to an earthed socket.




The power supply cable must be easily accessible after installing the appliance.

For any electrical work required to install this appliance, contact our Authorised Service Centre.

The manufacturer does not accept any responsibility for damage or injury through failure to comply with the above safety precaution.

## 6. CONTROL PANEL

## 6.1 Control panel description




## $(\mathbf{i})$

The options are not selectable with all washing programmes. Check the compatibility between options and washing programmes in the "Options compatibility with programmes" paragraph in the "Programmes" chapter. An option can exclude another one, in this case the appliance doesn't allow you to set the incompatible options together. Make sure the screen and touch buttons are always clean and dry.

- 1 Programme dial
- 2 Spin touch button
- 3 Temperature touch button
- 4 Display
- 5 Time Dry touch button
- 6 Auto Dry touch button
- 7 Start/Pause touch button
- 8 Delay Start
- 9 Dry Mode touch button and permanent Anti-crease option <sup>1</sup> 3s

- 10 Time Manager touch button and permanent Child Lock option 33
- 11 Stains touch button and permanent Extra Rinse option 🖽 ₃s
- 12 Prewash touch button
- 13 Mode Wash touch button
- 14 On/Off push button

## 6.2 Display




	The Temperature area:
	B Temperature indicator . * Cold water indicator.
0	Door locked indicator.
•	Child safety lock indicator.
6:88	The digital indicator can show:
	• Programme duration (e. g. CHQ, washing and/or drying phase).
	• Delay time (e. g. Ch).
	Cycle end (     C Cycle end (     Cycle end (     C Cycle end (     Cycle end (     Cycle end (     C Cycle end (     C Cycle end (     Cycle e
	• Warning code (e.g. E20).
	• Error indicator ().
	Time Manager indicator.
e	Time Dry indicator.
<b>@</b>	Steam phase indicator.
- <b>Ò</b> :-	Auto Dry indicator:
	<sup>−</sup> ♀ Iron dry
	· Cupboard dry
	🔆 Extra dry
<b>[</b>	Washing phase indicator
+ 	Extra Rinse indicator.
•••	Drum clean indicator. This is a recommendation to perform the drum cleaning. Re- fer to paragraph "Cleaning the drum" in "Care and cleaning" chapter.
Ũ	Anti-crease phase indicator. Read the 'Permanent Anti-crease' paragraph for more details.

555	Drying phase indicator.
1888	The spin area: Spin speed indicator
	<ul> <li>– – No Spin indicator. Spin phase is off.</li> </ul>
	Rinse Hold indicator.
88.ä <sub>m</sub>	Maximum load indicator (refer to "The SensiCare System load detection " para- graph). MAX It flashes when the laundry load exceeds the maximum declared load of the selected programme.
μ Γ	Add garments indicator. It lights at the beginning of the washing phase, when it is still possible to pause the appliance and add more laundry.

## 6.3 Multilingual badges

Adhesive badges in different languages are supplied with the appliance.

The desired badge can be glued next to the programme dial.



# 7. DIAL AND BUTTONS

## 7.1 Introduction

## $(\mathbf{i})$

The options/functions are not available with all washing programmes. Check the compatibility between options/functions and washing programmes in the "Programme Chart". An option/function can exclude another one, in this case the appliance doesn't allow you to set incompatible options/functions.

## 7.2 On/Off

Press this button for a few seconds to activate or deactivate the appliance. Two different tunes sound while switching the appliance on or off.

As the Stand-by function automatically deactivates the appliance after several minutes to reduce the energy consumption,

you may need to activate the appliance again.

For more details, refer to Stand-by paragraph in Daily Use chapter.

## 7.3 Programme dial

By rotating the programme dial it is possible to select the desired programme.

## 7.4 Temperature

When you select a washing programme, the appliance automatically proposes a default temperature.

Touch this button repeatedly until the desired temperature value appears on the display.

When the display shows the indicators  $_{-*}$ , the appliance does not heat the water.

## 7.5 Spin

When you set a programme, the appliance automatically sets the default spin speed.

Touch repeatedly this button to:

- Change the spin speed. The display shows only the spin speeds available for the set programme.
- Set the No Spin option – –. Set this option to deactivate all spin phases. The appliance performs the only draining phase of the selected washing programme. Set this option for very delicate fabrics. The rinses phase uses more water for some washing programmes
- Activate the Rinse Hold option. The final spin is not performed. The water of the last rinse is not drained out to prevent the fabrics from creasing. The washing programme ends with water in the drum.

The indicator is on display. The door stays locked and the drum turns regularly to reduce creasing. You must drain the water to unlock the door.

If you touch the Start/Pause  $\square$  button, the appliance performs the spinning phase and drains the water.

 $(\mathbf{i})$ 

The appliance empties the water out automatically after 18 hours approximately.

## 7.6 Mode Wash

This button allows to activate or deactivate the washing mode. When the washing mode is activated, the button indicator is on.

## 7.7 Prewash

With this option you can add a prewash phase to a washing programme.

The corresponding indicator above the touch button illuminates.

Use this option to add a pre-wash phase at 30  $^\circ\text{C}$  before the washing phase.

This option is recommended for heavily soiled laundry, especially if containing sand, dust, mud and other solid particles.

 $(\mathbf{i})$ 

The option can increase the programme duration.

## 7.8 Permanent Extra Rinse 📥 3s

With this option you can permanently have an extra rinse when you set a new programme.

To **activate/deactivate** this option, hold the Stains button pressed for 3 seconds until the indicator indicator comes on/goes off on the display.

When it is activated, the appliance will default to this option after you switch it off or change/ reset the programme.

 $(\mathbf{i})$ 

This option increases the programme duration.

## 7.9 Stains

Touch this button to add the stain phase to a programme.

The corresponding indicator above the touch button illuminates.

Use this option for laundry with hard stains to remove.

When you set this option, put the stain remover into compartment .

## $\overline{\mathbf{i}}$

This option increases the programme duration.

This option is not available with a temperature lower than 40 °C.

## 7.10 Time Manager

With this option you can reduce the programme duration depending on the load size and the degree of soiling.

When you set a washing programme, the

display shows the default duration and ----- dashes.

Touch Time Manager button to reduce the programme duration according to your needs. The display shows the new programme duration and a number of dashes will decrease accordingly:

---- suitable for a full load of normally soiled garments.

a quick cycle for a full load of lightly soiled garments.

-- very quick cycle for a smaller lightly soiled load (max. half load recommended).

the shortest cycle to freshen up a small amount of laundry.

The Time Manager is available only with the programmes in the table.

indicator	Cottons	Synthetics
1)	•	•
	•	•
	•	•
	•	•
-	•	•

1) Default duration for all programmes.

#### Time Manager with steam programmes $\langle w \rangle$

When setting a steam programme, this button allows to chose three steam levels and the programme duration is reduced accordingly:

- ---- : maximum.
- -- : medium.
- – : minimum.

## 7.11 Child Lock 🖬 3s

With this option you can prevent children from playing with the control panel.

To **activate/deactivate** this option, hold the Time Manager button pressed until the

indicator **comes on/goes off** on the display.

When it is activated, the appliance will default to this option after you switch it off or change/ reset the programme. If you press any button,

the indicator 🗖 blinks to indicate that the buttons are disabled.

## 7.12 Dry Mode

This button allows to activate or deactivate the drying mode. When the drying mode is activated, the button indicator is on.

## 7.13 Permanent Anti-crease 🗹 3s

This option adds a short anti-crease phase at the end of the programme.

This phase reduces fabric creasing and facilitates the fabric ironing.

To **activate/deactivate** this option, hold the Dry Mode button pressed for 3 seconds until

the indicator **T** comes on/goes off on the display.

When it is activated, the appliance will default to this option after you switch it off or change/ reset the programme.

#### (1)

This option can increase the programme duration.

When the programme stops the display shows **CO**, the indicator **T** and the Start/

Pause I led are lit. The drum performs smooth movements for about 30 minutes to keep the steam benefit. By touching any button the anti-crease movements stop and the door unlocks, the appliance proposes again the previous set programme.

To interrupt the anti-crease phase, you can also:

- Press the On/Off button for a few seconds to activate or the deactivate the appliance.
- Turning the programme dial in another position.

 $(\mathbf{i})$ 

A small laundry load helps to reach better results.

## 7.14 Delay Start

With this option you can delay the start of a programme to a more convenient time.

Touch the button repeatedly to set the required delay. The time increases in steps of 1 hour up to 20 hours.

The display shows the selected delay time.

After touching the Start/Pause  $\square$  button, the appliance begins the countdown and the door is locked.

## 7.15 Auto Dry

When the drying mode is activated, touch this button to set one the automatic dryness levels proposed by the appliance.

On the display the relevant dryness indicator goes on:

- <sup>O</sup> Iron dry: laundry to be ironed.
- Or Cupboard dry: laundry to be put in store.
- **Extra dry**: laundry to be fully dried.

# 8. SETTINGS

### 8.1 Introduction

i

When pressing a key combination, **do not tilt** your fingers downwards . The sensors of the underneath buttons are sensitive and may interfere with Your choice.

## 8.2 Acoustic signals

This appliance has different acoustic signals, that operate when:

- You activate the appliance (special short tune).
- You deactivate the appliance (special short tune).
- You touch the buttons (click sound).

 $(\mathbf{i})$ 

You can not set all automatic levels for each type of fabrics.

## 7.16 Time Dry

When the drying mode is activated, touch this button to set the time that suits the fabrics you have to dry (refer to "Timed drying" table). The display shows the set value.

Each time you touch this button the time value increases by 5 minutes.

i

You cannot set all time values for different types of fabrics.

## 7.17 Start/Pause ▷

Touch the Start/Pause  $\square$  button to start, pause the appliance or interrupt a running programme.

 $(\mathbf{i})$ 

The +J icon means that you can pause the cycle and add or remove garments. Read the 'Opening the door - Adding garments' section for more details.

- You make an invalid selection (3 short sounds).
- The programme is completed (sequence of sounds for about 2 minutes).
- The appliance has a malfunction (sequence of short sounds for about 5 minutes).

To **deactivate/activate** the acoustic signals when the programme is completed, touch the Wash Mode and the Prewash buttons simultaneously for about 2 seconds. The display shows On/Off

 $(\mathbf{i})$ 

If you deactivate the acoustic signals, they continue to operate when the appliance has a malfunction.

## 8.3 Operating Hours Counter

It is possible to visualise the total operating time of the appliance in hours, starting from the first switching on. This value will count operating time of the cycles (does not include pauses, delayed start time). To visualise this value, proceed as follows:

- 1. Switch the appliance on by pressing the On/Off button.
- 2. Press and hold the Prewash and Stains buttons for some seconds.
- **3.** After 3 seconds the total hours operated by the appliance are shown in the display: e.g. 1276 hours, the display shows the text Hr for 2 seconds, 12 (thousands and hundreds) for 2 seconds and 76 (tens and units).
- 4. To exit this mode, press any button or switch the appliance off by means of theOn/Off button.

# 9. BEFORE FIRST USE

## $(\mathbf{i})$

During installation or before first use you may observe some water in the appliance. This is a residual water left in the appliance after a full functional test in the factory to ensure the appliance is delivered to customers in perfect working order and is no cause for concern.

- 1. Make sure that all transit bolts have been removed from the appliance.
- 2. Make sure that the electrical power is available and the water tap is open.

## $(\mathbf{i})$

If the procedure does not work (due to timeout or wrong keys combination), switch the appliance off and repeat sequence from the beginning.

## 8.4 Factory Defaults

This function allows to restore the factory default options. To **activate** this option follow steps below:

- 1. Switch the appliance on by pressing On/Off button.
- **2.** Press and hold the Time Manager and Dry Mode buttons for some seconds.
- The display will show - for about 5 seconds.

 Pour 2 litres of water into the detergent compartment marked by III.

This action activates the drain system.

- Pour a small quantity of detergent into the compartment marked by <u>III</u>.
- Set and start a programme for cotton at the highest temperature without any laundry in the drum.

This removes all possible dirt from the drum and the tub.

## **10.** PROGRAMMES

## **10.1 Programme Chart**

Programme Default tempera- ture Temperature range	Reference spin speed Spin speed range	Maxi- mum Ioad	Programme description (Type of load and level of soiling)
QuickCare 69min 30 °C 60 °C - 30 °C	1400 rpm (1400 - 400 rpm)	5.0 kg	Programme to treat mixed fabrics (cotton and synthetic items) up to 5 kg. Complete washing programme that washes the daily soiled laundry efficiently at 30 °C and ensures a good performance in only 69 minutes. Add a drying phase to have a complete wash&dry treatment.
Eco 40-60 (Wash only mode) 40 °C <b>1)</b>	1400 rpm 1400 rpm - 400 rpm	9.0 kg	Low energy cycle for cottons. Decreases temperature and ex- tends time to reach good washing results.
Eco 40-60 + Cup- board dry level (Wash & Dry mode) 40 °C <b>2</b> )	1400 rpm 1400 rpm - 1000 rpm	5.0 kg	_
Eco 40-60 + Cup- board dry level (Dry only mode)	-	5.0 kg	White cotton and fast-coloured cotton.
Cottons 40 °C 90 °C - Cold	1400 rpm (1400- 400 rpm)	9.0 kg	White cotton and coloured cotton. Normally, heavily and lightly soiled items.
Synthetics 30 °C 60 °C - Cold	1200 rpm (1200 - 400 rpm)	3.0 kg	Synthetic items or mixed fabric items. Normally soiled items.
Delicates 30 °C 40 °C - Cold	800 rpm (1200- 400 rpm)	2.0 kg	Delicate fabrics such as acrylics, viscose and mixed fab- rics requiring gentler washing. Normally and lightly soiled items.
<ul> <li>         ・記         Wool         40 °C         40 °C - Cold     </li> </ul>	1200 rpm (1200 - 400 rpm)	1.5 kg	Machine washable wool, hand washable wool and other fabrics with «hand washing» care symbol <sup>3)</sup> .
Spin/Drain	1400 rpm (1400 - 400 rpm)	9.0 kg	All fabrics, except woollens and delicate fabrics. To spin the laundry and to drain the water in the drum.

Programme Default tempera- ture Temperature range	Reference spin speed Spin speed range	Maxi- mum load	Programme description (Type of load and level of soiling)
Rinse	1400 rpm (1400- 400 rpm)	9.0 kg	All fabrics, except woollens and very delicate fabrics. Programme for rinsing and spinning the laundry. The default spin speed is the one used for cotton programmes. Reduce the spin speed according to the type of laundry. If necessary, set the Extra Rinse option to add rinses. With a low spin speed, the appliance performs delicate rinses and a short spin.
Machine Clean 60 °C	1200 rpm (1200 - 400 rpm)		Maintenance cycle with hot water to clean and freshen the drum and to remove residue that may cause odour. For the best result use this cycle once a month. Before running this cycle, remove all items from the drum. In the washing phase compartment of the detergent dispenser, put the flap of the compartment in upward position. Pour a cup of chlorine bleach or a washing machine cleaner in the washing phase compartment. <b>DO NOT</b> use both together.
		-	i
			After the drum cleaning, run a further rinse cy- cle with empty drum and no detergent to re- move any residue of bleach.
			If you set this programme with the Dry Mode, the appliance performs the anti-fluff action. Refer to chapter 'Fluff in the fab- rics'.

#### Steam programme

Steam programme can be used for reducing wrinkles and odours<sup>4)</sup> of garments that just need to be refreshed, avoiding washing. The fabric fibres are relaxed and afterwards ironing becomes effortless. When the programme

is completed, quickly remove the laundry from the drum<sup>5</sup>). Steam programmes do not perform any hygienic cycle. Do not set this programme with the following type of items:

- Items that are not suitable for tumble drying.
- · Items with label "Dry clean only".

#### FreshScent System

**Electrolux fragrance**. If you use this special gentle fragrance, your laundry will scent as just washed. Read carefully the instructions supplied with the fragrance. Reduce the fragrance dosage when treating smaller load. By means of the Time Manager button, you can reduce the programme duration when treating items labeled to be washed at low temperature.

#### DO NOT:

- · Tumble dry the garments treated with fragrance. Its benefit would evaporate.
- · Use the fragrance with different purposes than those here described.
- Use the fragrance on new garments. New garments may contain residual finishing compounds which are not compatible with it.

## $(\mathbf{i})$

The fragrance is available on Electrolux web shop or by authorised dealer.

Programme Default tempera- ture Temperature range	Reference spin speed Spin speed range	Maxi- mum Ioad	Programme description (Type of load and level of soiling)
G∰ Steam Refresh	-	1.0 kg	<b>Cotton, synthetic and mixed items.</b> Special steam cycle without washing that can be used to prepare your dried laundry for ironing or refresh garments worn once. This programme reduces creases, odours and relaxes the fibres. Do not use any detergent.
Jeans 30 °C 40 °C - Cold	1200 rpm 1200 rpm - 400 rpm	3.0 kg	<b>Denim clothing and jersey items</b> . Normal soiled. This pro- gramme performs a gentle rinsing phase, designed for denim, that reduces fading and does not cause washing powder resi- dues on the fibres.
ట్ర Outdoor 30 °C 40 °C - Cold	1200 rpm (1200- 400 rpm)	2.0 kg	(i) Do not use fabric softener and make sure that there is no softener residue in the detergent dispenser.
			Outdoor clothing, technical, sport fabrics, waterproof and breathable jackets, shell jackets with a removable fleece or inner insulation.
			i
			By performing a combined wash and dry pro- gramme, the drying phase also acts as water repellent restorer. <b>Make sure that the gar-</b> <b>ment care label permits tumble drying.</b>
င္မ်ာ (က္က) Hygiene	1400 rpm 1400 rpm -	9.0 kg	White cotton items. This high-performance wash programme combined with steam vapour, removes more than 99,99% of
60 °C	400 rpm		bacteria and viruses <sup>6</sup> ) keeping the temperature above 60°C throughout the washing phase; with an additional action on the fibers thanks to a vapour phase, an enhanced rinsing phase ensures a proper removal of detergent and micro-organism residues. This programme ensures also a proper reduction of pollens/allergenic items.
OneGo 20/60min 30 °C 40 °C - 30 °C	1200 rpm	1.0 kg	Programme to treat up to 1 kg of <b>mixed synthetic shirts</b> load in 20 minutes only. Add a drying phase to have a complete wash&dry treatment in 60 minutes.

Programme Default tempera-	Reference spin speed	Maxi- mum
ture	Spin speed	load
Temperature	range	
range		

#### Programme description (Type of load and level of soiling)

•

Reset position. The display shows dashes only.

1) According to Commission Regulation EU 2019/2023. This programme at default temperature and spin speed, in washing only mode, with rated capacity 9.0 kg is able to clean normally soiled cotton laundry declared to be washable at 40 °C or 60 °C, together in the same cycle.

#### (i)

For the reached temperature in the laundry, the programme duration and other data, please refer to 'Consumption Values' chapter.

The most efficient programmes in terms of energy consumption are generally those that perform at lower temperatures and longer duration.

2) According to Commission Regulation EU 2019/2023. This programme at default temperature and spin speed, in washing and drying mode, with rated capacity 5.0 kg and with Cupboard dry level performs the wash and dry cycle able to clean normally soiled cotton laundry declared to be washable at 40 °C or 60 °C, together in the same cycle and, after drying phase, the laundry can be immediately stored in a cupboard.

3) During this cycle the drum rotates slowly to ensure a gentle wash. It can seem that the drum doesn't rotate or doesn't rotate properly, but this is normal for this programme.

4) Steam programme doesn't remove particularly intense odour.

5) After the steam treatment the laundry can be humid. Hang items out for a few minutes.

**6)** Tested for Staphylococcus aureus, Enterococcus faecium, Candida albicans, Pseudomonas aeruginosa and MS2 Bacteriophage in external test performed by Swissatest Testmaterialien AG in 2021 (Test Report No. 202120117).

#### Programme options compatibility

Programme	Spin	– – – No Spin		Prewash 1)	t+ 35	Time Manager	Stains	낸 <sub>3s</sub>	Auto Dry	Time Dry	Delay Start
QuickCare 69min	•	•	•		-				•	•	-
Eco 40-60	•		•						∎2)	•	•
Cottons	•	•	•	•	•	•	•	•	•	•	•
Synthetics	•	•	•	•	•	•	•	•	•	•	•
Delicates	•	•	•		•			•	•	•	•

Programme	Spin	– – – No Spin		Prewash 1)	t. 	Time Manager	Stains	<u>चि</u> 35	Auto Dry	Time Dry	Delay Start
کی ا <u>ک</u> Wool	•	•	•						•	•	•
Spin/Drain	•	∎3)									
Rinse	•	•	•		•			•			•
Machine Clean	•	•							•	•	•
ଦ୍କି) Steam Refresh						•					•
Jeans	•	•			•		•	•	<b>∎</b> 2)	•	•
හි Outdoor	•	•	•		•			•	•	•	•
င္မ်ာ (က္က) Hygiene	•	-	•		•		•	-		•	•
OneGo 20/60min								•	•	•	

Prewash and Stains cannot be selected together.
 Iron Dry level is not available.

3) If you set the No Spin option, the appliance performs draining only.

▲ = Only Cupboard dry level is available.

### Suitable detergents for each programme

Programme	Universal powder <sup>1)</sup>	Liquid Univer- sal	Liquid for col- oureds	Delicates woollens	Special
QuickCare 69min	•	•	•		
Eco 40-60	•	•	<b>A</b>		
Cottons	•	•	<b>A</b>		
Synthetics	<b>A</b>	*	<b>A</b>		
Delicates				<b>A</b>	<b>A</b>

Programme	Universal powder <sup>1)</sup>	Liquid Univer- sal	Liquid for col- oureds	Delicates woollens	Special
Wool				*	<b>A</b>
Jeans			<b>A</b>	<b>A</b>	<b>▲</b>
Outdoor				<b>A</b>	<b>▲</b>
Hygiene	۸	•			•
OneGo 20/60min		•	<b>A</b>		

1) At temperature higher than 60 °C the use of powder detergent is recommended.

- = Recommended
- -- = Not recommended

## 10.2 Woolmark Wool Care - Blue



 The wool wash cycle of this machine has been approved by The Woolmark

### 10.3 Automatic drying

 $(\mathbf{i})$ 

Company for the washing of wool garments labelled as "hand wash" provided that the products are washed according to the instructions on the garment label and those issued by the manufacturer of this washing machine. M2103.

 The wool drying cycle of this machine has been tested and approved by The Woolmark Company. The cycle is suitable to dry wool garments which are labelled "hand wash" provided that the garments are washed in a Woolmark endorsed hand washing cycle and dried according to the instructions issued by the manufacturer. M2104.

The Woolmark symbol is a Certification mark in many countries.

Initial cycle times for programmes with Auto Dry option are only
estimates, the actual drying time may slightly differ from the time
displayed.

Dryness Level	Type of fabric	Load		
-) Extra Dry	Cottons and Linen (bathrobes, bath towels, etc)	up to 5.0 kg		
For towelling materials	Denim garments	up to 3.0 kg		
<b>Cupboard Dry</b> For items to be stored	Cottons and Linen (bathrobes, bath towels, etc)	up to 5.0 kg		

Dryness Level	Type of fabric	Load	
	Synthetics and mixed fabrics (jumpers, blouses, underwear, household and bed linen)	up to 3.0 kg	
	<b>Delicate fabrics</b> (acrylics, viscose and delicate mixed fabrics)	up to 2.0 kg	
	Wool items (woollen jumpers)	up to 1.0 kg	
	Outdoor sporting garments (outdoor clothing, technical, sport fabrics, waterproof and breathable jackets, shell jackets)	up to 2.0 kg	
	Denim garments	up to 3.0 kg	
-☆- Iron Dry Suitable for ironing	Cottons and Linen (sheets, tablecloths, shirts, etc)	up to 5.0 kg	

## 10.4 Timed drying

Dryness Level	Type of fabric	Load (kg)	Spin speed (rpm)	Suggested du- ration (mins)
Extra Dry For towelling materi- als	Cottons and Linen (bathrobes, bath towels, etc)	5.0	1400	170 - 190
		3.0	1400	110 - 130
		1.0	1400	50 - 60
	Denim garments	3.0	1200	120 - 140
		1.0	1200	70 - 90
Cupboard Dry For items to be stor- ed	Cottons and Linen (bathrobes, bath towels, etc)	5.0	1400	160 - 180
		3.0	1400	100 - 120
		1.0	1400	40 - 50
	Synthetics and mixed fabrics (jumpers, blouses, underwear, household and bed linen)	3.0	1200	80 - 100
		1.0	1200	45 - 55
	Delicates (acrylics, viscose and delicate mixed fabrics)	2.0	1200	100 - 120
		1.0	1200	60 - 80

Dryness Level	Type of fabric	Load (kg)	Spin speed (rpm)	Suggested du- ration (mins)
	Wool (woollen jumpers)	1.0	1200	110 - 130
	Outdoor sporting garments (outdoor clothing, technical, sport fabrics, water- proof and breathable jackets, shell jackets)	2.0	1200	120 - 140
		1.0	1200	80 - 90
	Denim garments	3.0	1200	110 - 130
		1.0	1200	60 - 80
Iron Dry Suitable for ironing	Cottons and Linen (sheets, tablecloths, shirts, etc)	5.0	1400	90 - 110
		3.0	1400	55 - 75
		1.0	1400	30 - 40

## 11. DAILY USE - WASHING ONLY

### A WARNING!

Refer to Safety chapters.

## 11.1 Activating the appliance

- 1. Connect the mains plug to the mains socket.
- 2. Open the water tap.
- Press the On/Off button for a few seconds to activate the appliance.
   A short tune sounds


A short tune sounds.

## 11.2 Loading the laundry

- 1. Open the appliance door.
- 2. Empty the pockets and unfold the items before you put them in the appliance.
- **3.** Put the laundry in the drum, one item at a time.

Do not put too much laundry in the drum.

**4.** Close the door firmly.




## 

Make sure that no laundry gets caught between the seal and the door to avoid risk of water leakage and damage to the laundry.

## $(\mathbf{i})$

Washing heavily oiled, greasy stains could cause damage to rubber parts of the washing machine.

## 11.3 Filling the detergent and additives



Compartment for prewash phase, soak programme or stain remover.

Compartment for washing phase.

😸 - Compartment for fabric softener and other liquid treatments (fabric conditioner, starch).

MAX - Maximum level for quantity of liquid additives.

- Flap for powder or liquid detergent.

## $(\mathbf{i})$


Always follow the instructions that you find on the packaging of the detergent products, but we recommend that you do not exceed the maximum indicated level (MAX). This quantity will however guarantee the best washing results.

## (i)


After a washing cycle, if necessary, remove any detergent residue from the detergent dispenser.

#### 11.4 Check the position of the detergent flap


1. Pull out the detergent dispenser until it stops.



- 2. Press the lever down to remove the dispenser.
- 3. To use powder detergent, turn the flap up.




4. To use liquid detergent, turn the flap down.



With the flap in the position **DOWN**:

- Do not use gelatinous or thick liquid detergents.
- Do not exceed to liquid detergent dose indicated on the flap.
- Do not set the prewash phase.
- Do not set the delay start function. •
- 5. Measure out the detergent and the fabric conditioner.
- 6. Carefully close the detergent dispenser.



Make sure that the flap does not cause a blockage when you close the drawer.

## 11.5 Bleach

Alternatively the softener, it is also possible to

use a bleach agent in the compartment & with the programmes for white cottons. Proceed as follows:

- **1.** Put the bleach in the compartment  $\bigotimes$ . Do not exceed the **«MAX»** mark in the detergent dispenser drawer.
- 2. Run a programme for white cottons.
- **3.** At the end of the programme, run the rinse programme or a programme with the rinse option. Use softener, if desired. This helps to eliminate any bleach residues.

i

Never pour bleach and softener into the compartment at the same time.

## 11.6 Setting a programme

1. Turn the programme dial to select the desired washing programme. The related programme indicator comes on.

The Eco 40-60 is the programme to which the information of the energy label relates.

The indicator of the Start/Pause  $\square$  button flashes.

The display shows an indicative programme duration, the maximum declared load for the set programme (only for a few seconds), the default temperature, the default spin speed and the washing phase indicators (when available).

2. To change the temperature and/or the spin speed, touch the related buttons.

3. If desired, set one or more options by touching the related buttons. The related indicators come on in the display and the given information changes accordingly.

#### $(\mathbf{i})$

In case a selection is **not possible** an acoustic signal sounds.

## 11.7 Starting a programme

Touch the Start/Pause I button to start the programme. It is not possible to start the programme when the indicator of the button is off and doesn't flash (e.g. the door is open). The related indicator stops flashing and stays on.

The programme starts, the door is locked.

The display shows the indicator -0 and the

+J indicator appears to indicate that it is still possible to stop the cycle and add garments.

 $(\mathbf{i})$ 

The drain pump can operate shortly before the appliance fills water.

# 11.8 Starting a programme with the delay start

- 1. Touch the Delay Start button repeatedly until the display shows the desired delay time. The related indicator comes on.
- 2. Touch the Start/Pause ▷II button. The appliance door locks and starts the countdown of the delay start. The display

shows the indicator -0. When the countdown is completed, the programme starts automatically.

Cancelling the delay start after the countdown has started

To cancel the delay start:

- 1. Touch the Start/Pause pause the appliance. The related indicator flashes.
- 2. Touch the Delay Start button repeatedly until the display shows and the related indicator goes off.
- 3. Touch the Start/Pause ▷II button again to start the programme immediately.

Changing the delay start after the countdown has started

To change the delay start:

- 1. Touch the Start/Pause pause the appliance. The related indicator flashes.
- 2. Touch the Delay Start button repeatedly until the display shows the desired delay time.
- 3. Touch the Start/Pause ▷II button again to start the new countdown.

# 11.9 The SensiCare System load detection

## $(\mathbf{i})$

The programme duration in the display is referred to a **medium/high load**.

After touching the Start/Pause **▷II** button, the maximum declared load indicator goes off, the SensiCare System starts the laundry load detection:

1. The appliance detects the load in the first 30 seconds. In the programmes where Time Manager is available, during this

phase the Time Manager bars ---placed below the time digits play a simple animation. The drum rotates shortly.

2. The programme duration could be adjusted accordingly and could increase or decrease. After further 30 seconds, the water filling starts.

At the end of the load detection, in case of

drum overload, the indicator MAX is flashing in the display:

In this case, for 30 seconds, it is possible to pause the appliance and remove the exceeding garments.

Once removed the exceeding garments, touch the Start/Pause I button to start the programme again. The SensiCare phase can be repeated up to three times (see point 1).

**Important!** If the laundry amount will not be reduced, the washing programme starts anyway, despite the overload. In this case, it

will be not possible to guarantee the best washing results.

 $(\mathbf{i})$ 

About 20 minutes after the programme start, the programme duration could be adjusted again depending on the capacity of water absorption of the fabrics.

## $(\mathbf{i})$

The SensiCare detection is carried out with complete washing programmes only and if the programme duration has not been reduced by means of the Time Manager button.

 $(\mathbf{i})$ 

The SensiCare System is not available with all programmes such as :Wool, Rinse and programmes with short cycles.

# 11.10 Interrupting a programme and changing the options

When the programme is running, you can change **only some** options:

- **1.** Touch the Start/Pause **b** button. The related indicator flashes.
- 2. Change the options. The given information in the display changes accordingly.

**3.** Touch the Start/Pause D button again. The washing programme continues.

# 11.11 Cancelling a running programme

- 1. Press the On/Off button to cancel the programme and to deactivate the appliance.
- 2. Press the On/Off button again to activate the appliance.

Now, you can set a new washing programme.

## $(\mathbf{i})$

If the SensiCare phase is already carried out and the water filling is already started, the new programme starts **without repeating the SensiCare phase**. The water and the detergent are not drained out in order to avoid waste. The display shows the maximum duration of the programme, updating it about 20 minutes after the starting of the new programme.

There is also an alternative way of cancelling:

1. Touch the Start/Pause D button.

2. Rotate the selector knob to the "Reset"

position •.

3. Wait for 1 second. The display shows

Now, you can set a new washing programme.

# 11.12 Opening the door - Adding garments

If the  $\widehat{+J}$  icon is on, you can always open the door.

While a programme or the delay start operates, the appliance door is locked. The

display shows the indicator -0.

## $(\mathbf{i})$

If the temperature and level of the water in the drum are too high and/or the drum is still rotating you should not open the door.

To add or to remove garments:

1. Touch the Start/Pause ▷II button.

In the display the related door lock indicator goes off.

 Open the appliance door. If necessary, add or remove the garments. Close the door and touch the Start/Pause button.

The programme or the delay start continues.

## 11.13 End of the programme

When the programme has finished, the appliance stops automatically. The acoustic

signals operate (if they are active). The display shows

The indicator of the Start/Pause  $\fbox{I}$  button goes off.

The door unlocks and the indicator -0 goes off.

1. Press the On/Off button to deactivate the appliance.

After five minutes from the end of the programme, the energy saving function automatically deactivates the appliance.

 $(\mathbf{i})$ 

When you activate the appliance again, the display shows the end of the previous programme. Turn the programme dial to set a new cycle.

- 2. Remove the laundry from the appliance.
- 3. Make sure that the drum is empty.
- Keep the door and the detergent dispenser slightly ajar to prevent mildew and odours.

# 11.14 Draining water out after end of cycle

If you have chosen a programme or an option that does not empty out the water of the last rinse, the programme is completed, but:

- The time area shows OOO and the display shows the door locked -0.
- The indicator of the Start/Pause button starts flashing.
- The drum still turns at regular intervals to prevent creases in the laundry.
- The door stays locked.
- You must drain the water to open the door:
- If necessary, touch the Spin button to decrease the spin speed proposed by the appliance.
- 2. Press the Start/Pause  $\bigcirc$  button: the appliance drains the water and spins.

The option indicator Rinse Hold disappears.

## $(\mathbf{i})$

If you have selected No Spin - -, the appliance will only drain the water.

- When the programme is completed and the door locked indicator - goes off, you can open the door.
- **4.** Press the On/Off button for a few seconds to deactivate the appliance.

## 11.15 Stand-by function

The Stand-by function automatically deactivates the appliance to reduce the energy consumption when:

 You do not use the appliance for 5 minutes when no programme is running. Press the button On/Off to activate the appliance again.  5 minutes after the end of the washing programme.

Press the On/Off button to activate the appliance again.

The display shows the end of the last programme.

Turn the programme dial to set a new cycle.

If the dial is rotated to the "Reset" position •, the appliance automatically turns off in 30 seconds.

 $(\mathbf{i})$ 

If you set a programme or an option that ends with water in the drum, the Standby function **doesn't deactivate** the appliance to remind you to drain the water.

# 12. DAILY USE - WASHING & DRYING

## 

Refer to Safety chapters.

## i

This appliance is an automatic washer dryer.

# 12.1 Complete wash&dry programme

Non-automatic wash&dry programmes

In some washing programmes, you can combine Mode - Wash and Mode - Dry for running a complete wash&dry programme.

Proceed as follows:

- 1. After loading laundry and detergent, press the On/Off button for some seconds to activate the appliance.
- 2. Load the laundry one item at a time.
- **3.** Put the detergent and the additives in the appropriate compartment.
- 4. Turn the programme dial to the washing programme. The appliance defaults to the washing only mode and the indicator of the Mode Wash button is on. The

display shows the default temperature and spin. If necessary, change them according to your laundry. The display also shows the maximum recommended load for washing phase.

- 5. Set the desired options, if there are available.
- 6. Tap on the Mode Dry button to activate also the drying function. Both indicators of the Mode Wash and Mode Dry buttons

are on. The indicators (M) and  $(\hat{\Psi})$  appear on the display. The display also shows the maximum recommended load for a washing and drying programme (e.g. 5.0 kg for cottons).

#### 12.2 Washing and Drying -Automatic levels

- 1. Tap on the Auto Dry button repeatedly until the display shows the required dryness level. The indicators in the display illuminate accordingly:
  - a. O Iron dry: for cotton items;
  - b. Cupboard dry: for cotton and synthetic items;
  - c. 🗮 Extra dry: for cotton items.

# The time value on the display is the duration of both cycles washing and drying, calculated on a default load size.

 $(\mathbf{i})$ 

To have a good drying by using less energy and in a shorter time, the appliance does not let you set a too low spin speed for the items to be washed and dried.

2. Touch button Start/Pause ▷II to start the programme. The SensiCare estimation starts.

In the display the door locked **-0** indicator comes on.

The display also shows the remaining programme time.

## 12.3 Washing and Timed Drying

 Tap on the Time Dry button repeatedly to set the desired time value (see the "Timed drying" table in the "Programmes"

chapter). The drying level indicator 🔅

goes off and the indicator according to the set of the

2. Touch the Start/Pause ▷I button to start the programme. The SensiCare estimation starts.

In the display the door locked **-0** indicator comes on.

The display also shows the remaining programme time.

# 12.4 At the end of the drying programme

• The appliance stops automatically.

# 13. DAILY USE - DRYING ONLY

## 

Refer to Safety chapters.

 $(\mathbf{i})$ 

This appliance is an automatic washer dryer.

- The acoustic signals operate (if they are active).
- In the display COD comes on.
- The indicator of the Start/Pause I button goes off. The door locked - goes off and the door unlocks.

The appliance continues to operate with the anti-crease phase for approximately 30 minutes or more if Anti-crease option was set.

The anti-crease phase reduces creasing. You can remove the laundry before the anti-crease phase is completed. We recommend, for better results, that you remove the laundry when the phase is almost completed or completed. The

indicator **T** remains lit.

• Press the On/Off button for some seconds to deactivate the appliance.

## $(\mathbf{i})$

After some minutes from the end of the programme, the energy saving function deactivates the appliance automatically.

- 1. Remove the laundry from the appliance.
- 2. Make sure that the drum is empty.

## $(\mathbf{i})$

After drying phase, clean the drum, the seal and the inside of the door with a wet cloth.

## 13.1 Preparation to drying

- 1. Press the On/Off button for some seconds to activate the appliance.
- 2. Load the laundry one item at a time.
- 3. Turn the programme dial to the programme suitable for the items to dry. The appliance defaults to the washing

only mode and the indicatorMode - Wash is on.

 Tap on the Mode - Dry button twice to perform drying only. The indicator of Mode - Dry button illuminates and the indicator of Mode - Wash button goes off. The indicators ()) and () appear on the display and the indicator () disappears.

 $(\mathbf{i})$ 

When drying a big amount of laundry, to have good drying performances, make sure that the laundry itself is not rolled up and that is uniformly distributed in the drum.

## 13.2 Drying - Automatic levels

- 1. Tap on the Auto Dry button repeatedly until the display shows the required dryness level. The indicators in the display illuminate accordingly:
  - a. Or Iron dry: for cotton items;
  - b. Or Cupboard dry: for cotton and synthetic items;

#### c. \* Extra dry: for cotton items. The display shows the drying programme duration.

2. Touch the Start/Pause ▷ II button to start the programme.

In the display the door locked **--** indicator comes on and the door is locked. The display also shows the remaining programme time.

## 13.3 Timed Drying

 Tap on the Time Dry button repeatedly to set the desired time value (see the "Timed drying" table in the "Programmes"

chapter). The drying level indicator 🔅

goes off and the indicator (2) comes on. Each time you tap on this button the time value increases by 5 minutes. The display shows the set new time value. 2. Touch the Start/Pause ▷II to start the programme.

In the display the door locked **--1** indicator comes on and the door is locked. The display also shows the remaining programme time.

# 13.4 At the end of the drying programme

- The appliance stops automatically.
- The acoustic signals operate (if they are active).
- In the display COD comes on.
- The indicator of the Start/Pause I button goes off. The door locked - goes off and the door unlocks.

The appliance continues to operate with the anti-crease phase for approximately 30 minutes or more if Anti-crease option was set.

The anti-crease phase reduces creasing. You can remove the laundry before the anti-crease phase is completed. We recommend, for better results, that you remove the laundry when the phase is almost completed or completed. The

indicator 🐨 remains lit.

• Press the On/Off button for some seconds to deactivate the appliance.

## $(\mathbf{i})$

After some minutes from the end of the programme, the energy saving function deactivates the appliance automatically.

- 1. Remove the laundry from the appliance.
- 2. Make sure that the drum is empty.

### $(\mathbf{i})$

After drying phase, clean the drum, the seal and the inside of the door with a wet cloth.

# 14. FLUFF IN THE FABRICS

During the washing and/or drying phase, some types of fabric, (sponge, wool, sweatshirt) could release fluff.

The released fluff could stick to the fabrics during the next cycle.

This inconvenient increases with technical fabrics.

To prevent the fluff in your laundry, we recommend that you:

- To do not wash dark fabrics after you washed and dried light coloured fabrics (hand towel, wool, sweatshirt) and the contrary.
- To dry this type of fabrics at open air when they are washed the first time.
- To clean the drain filter.
- After the drying phase, clean the empty drum, the gasket and the door with a wet cloth.

## **15. HINTS AND TIPS**

#### 

Refer to Safety chapters.

### 15.1 The laundry load

- Divide the laundry into: white, coloured, synthetics, delicates and wool.
- Follow the washing instructions on the laundry care labels.
- Do not wash white and coloured items together.
- Some coloured items can discolour with the first wash. We recommend that you wash them separately for the first couple of times.
- Turn multilayered fabrics, wool and items with printed illustrations inside out.
- Pre-treat stubborn stains.
- Wash stubborn stains with a special detergent.
- Be careful with curtains. Remove the hooks and put the curtains in a washing bag or pillowcase.

# To remove the fluff inside the drum, set a special programme:

- Empty the drum.
- Clean the drum, the gasket and the door with a wet cloth.
- Set the Machine Clean programme and the Mode - Dry together to activate the anti-fluff action.
- Touch the Start/Pause button to start the programme.

(i)

If the appliance is frequently used, carry out the cleaning programme regularly.

- A very small load can cause balance problems with the spin phase leading to excessive vibration. If this occurs:
  - a. interrupt the programme and open the door (refer to "Daily Use" chapter);
  - manually redistribute the load so that the items are spaced evenly around the tub;
  - c. press the Start/Pause button. The spin phase continues.
- Button up pillowcases, close zippers, hooks and poppers. Tie up belts, cords, shoelaces, ribbons and any other loose elements.
- Do not wash laundry without hems or with cuts. Use a washing bag to wash small and/or delicate items (e.g. underwired bras, belts, tights, shoelaces, ribbons, etc. ).



Empty pockets and unfold the items.



## 15.2 Stubborn stains

For some stains, water and detergent is not sufficient.

We recommend that you pre-treat these stains before you put the items in the appliance.

Special stain removers are available. Use the special stain remover that is applicable to the type of stain and fabric.

Do not spray stain remover on garments near the appliance as it is corrosive to the plastic parts.



## 15.3 Detergent type and quantity

The choice of detergent and use of correct quantities not only affects your wash performance, but also helps to avoid waste and protect the environment:

 Use only detergents and other treatments specially made for washing machines.
 First, follow these generic rules:

- powder detergents (also tablets and single-dose detergents) for all types of fabric, excluding delicate. Prefer powder detergents containing bleach for whites and laundry sanitization,
- liquid detergents (also single-dose detergents), preferably for low temperature wash programmes (60 °C max) for all types of fabric, or special ones for woollens only.
- The choice and quantity of detergent will depend on: type of fabric (delicates, woollens, cottons, etc), the colour of clothes, size of the load, degree of soiling, wash temperature and hardness of the water used.
- Follow the instructions that you find on packaging of the detergents or other treatments without exceeding the

indicated maximum level (MAX).

- Do not mix different types of detergents.
- · Use less detergent if:
  - you are washing a small load,
  - the laundry is lightly soiled,
  - there is large amounts of foam during washing.
- When using detergent tabs or pods, always put them inside the drum, not in the detergent dispenser and follow the manufacturer's recommendations.

#### Insufficient detergent may cause:

- unsatisfactory washing results,
- the wash load to turn grey,
- · greasy clothes,
- mould in the appliance.

#### Excessive detergent may cause:

- sudsing,
- reduced washing effect,
- inadequate rinsing,
- a greater impact for the environment.

## 15.4 Ecological hints

To save water, energy and to help protect the environment, we recommend that you follow these tips:

- Normally soiled laundry may be washed without prewash in order to save detergent, water and time (the environment is protected too!).
- Loading the appliance to the maximum capacity indicated for each

programmes helps to reduce energy and water consumption.

- With adequate pre-treatment, stains and limited soiling can be removed; the laundry can then be washed at a lower temperature.
- To use the correct quantity of detergent, refer to the quantity suggested by the detergent producer and check the water hardness of you domestic system. Refer to 'Water hardness'.
- Set the **maximum possible spin speed** for the selected programme for saving energy during drying phase!

### 15.5 Water hardness

If the water in your area is hard or medium hard, we recommend that you use a water softener for washing machines.

The water is hard or medium hard when the hardness exceeds 8dH.

In areas where the water is soft it is not necessary to use a water softener.

To find out the water hardness in your area, contact your local water authority.

Use the correct quantity of water softener. Follow the instructions that you find on the packaging of the product.

## 15.6 Prepare the drying cycle

- Open the water tap.
- Check if the drain hose is connected properly. Refer to installation chapter for more information.
- For the maximum laundry load of the drying programmes, refer to the drying programmes table.

### 15.7 Items not suitable for drying

## Do not set a drying programme for this laundry:

- Synthetic curtains.
- · Pieces of clothing with metal inserts.
- Nylon stockings.
- Quilts.
- Bed covers.
- Duvets.
- Anoraks.
- Sleeping bags.

- Fabrics with residue of hair sprays, nail solvents or similar.
- Garments with foam-rubber or materials similar to foam-rubber.

### 15.8 Garment labels

When you dry the laundry, obey the indications on the labels of the manufacturers:

- 🖸 = The drying cycle is at high temperature
- 🖸 = The drying cycle is at reduced temperature
- $\square$  = The item can not be tumble dried.

### 15.9 Drying cycle duration

The drying time can change depending on:

- speed of the last spin
- dryness level
- type of laundry
- weight of the load

### 15.10 Additional drying

If, at the end of the drying programme, the laundry is still damp, set a short drying cycle again.

#### / WARNING!

To avoid creasing and shrinkage do not overdry the laundry.

### 15.11 General Tips

Refer to the «Timed drying» table to find the **average** drying times.

Experience will help you to dry the laundry better. Take note of the duration of the cycles done before.

To avoid the static charge at the end of the drying cycle:

- 1. Use fabric conditioner in the washing cycle.
- 2. Use special fabric conditioner for tumble dryers.
- 3. Do not pour any detergent or softener before a drying cycle.

- 4. Do not dry rough and smooth textiles together, to avoid scorching on smooth garments.
- 5. Remove all objects from garment pockets, especially melting objects.

## **16.** CARE AND CLEANING

### 

Refer to Safety chapters.

### 16.1 Periodic cleaning schedule

## Periodic cleaning helps to extend the life of your appliance.

After each cycle, keep the door and the detergent dispenser slightly ajar to get air circulation and dry the humidity inside the appliance: this will prevent mildew and odours.

If the appliance is not used for a long time: close the water tap and unplug the appliance.

#### Indicative periodic cleaning schedule:

Descaling	Twice a year
Maintenance wash	Once a month
Clean door seal	Every two months
Clean drum	Every two months
Remove fluff inside the drum	Twice a month <b>1)</b>
Clean detergent dispens- er	Every two months
Clean drain pump filter	Twice a year
Clean the inlet hose and the valve filter	Twice a year

1) Refer to "Fluff in the fabrics" chapter.

The following paragraphs explain how you should clean each part.

When the drying programme is completed remove the laundry in a short time.

## 16.2 Removing foreign objects

 $(\mathbf{i})$ 

Make sure that pockets are empty and all loose elements are tied up before running your cycle. Refer to "The laundry load" in "Hints and tips".

Remove any foreign objects (such as metal clip, buttons, coins, etc) that you may find in the door seal, the filters and the drum. Refer to "Door seal with double lip trap", "Cleaning the drum", "Cleaning the drain pump" and "Cleaning the inlet hose and the valve filter" paragraphs. If necessary, please contact the Authorised Service Centre.

### 16.3 External cleaning

Clean the appliance with mild soap and warm water only. Fully dry all the surfaces.

Do not use a scouring pads or any scratching material.

### 

Do not use alcohol, solvents or chemical products.

### ⚠̀ CAUTION!

Do not clean the metal surfaces with chlorine-based detergent.

### 16.4 Descaling

 $(\mathbf{i})$ 

If the water in your area is hard or medium hard, we recommend that you use a water softener for washing machines.

The water is hard or medium hard when the hardness exceeds 8dH.

Regularly examine the drum to check for limescale.

The regular detergents already contain water softening agents, but we recommend to run a cycle with empty drum and a descaling product occasionally.

### I

Always follow the instructions that you find on the packaging of the product.

### 16.5 Maintenance wash


The repeated and prolonged use of low temperature programmes can cause detergent deposits, fluff residues, bacterial growth inside the drum and the tub. This could generate bad odours and mildew. To eliminate these deposits and clean the inner part of the appliance, run a maintenance wash regularly (at least once a month).

 $(\mathbf{i})$ 

Refer to "Cleaning the drum" paragraph.

### 16.6 Door seal

This appliance is designed with a **self cleaning draining system**, allowing light fluff fibers that fall off the clothes to be drained out with the water. Regularly examine the seal. Coins, buttons, other small items can be recovered at the end of the cycle.



Clean it when needed, using ammonia cream cleanser agent without scratching the seal surface.

 $(\mathbf{i})$ 

Always obey the instructions that you find on the packaging of the product.

### 16.7 Cleaning the drum

Regularly examine the drum to prevent unwanted deposits.

Rust deposits in the drum may occur due to rusting foreign body in the washing or tap water containing iron

Clean the drum with special products for stainless steel.

i

Always follow the instructions that you find on the packaging of the product. Do not clean the drum with acidic descaling products, scouring products containing chlorine or iron or steel wool.

For a thorough clean:

- 1. Remove all laundry from the drum.
- 2. Run the Machine Clean programme. For more details, refer to washing programme table.
- **3.** Add a small quantity of powder detergent into the empty drum, in order to rinse out any left residues.

### $(\mathbf{i})$


Occasionally, at the end of a cycle the

display may show the icon **\*\***: this is a recommendation to perform the "drum cleaning". Once the drum cleaning has been performed, the icon disappears.


# 16.8 Cleaning the detergent dispenser


To prevent possible deposits of dried detergent or clotted fabric softener and/or formation of mould in the detergent dispenser drawer, once in a while carry out the following cleaning procedure:

1. Open the drawer. Press the catch downwards as indicated in the picture and pull it out.




2. Remove the top part of the additive compartment to aid cleaning. Make sure that all detergent residue is removed from the upper and lower part of the recess. Use a small brush to clean the recess.





- 3. Flush the detergent drawer out under running warm water to remove any traces of accumulated detergent. After cleaning, replace the top part in its position.
- 4. Insert the detergent drawer into the guide rails and close it. Run the rinsing programme without any clothes in the drum.



## 16.9 Cleaning the drain pump

### ⚠ WARNING!

Disconnect the mains plug from the mains socket.

### (**i**)

Regularly check the drain pump filter and make sure that it is clean.

Clean the drain pump if:


- The appliance does not drain the water.
- The drum does not turn.
- The appliance makes an unusual noise because of the blockage of the drain pump.
- The display shows the alarm code  $\mathcal{E}\mathcal{E}\mathcal{O}$ .

### A WARNING!


- Do not remove the filter while the appliance operates.
- Do not clean the pump if the water in the appliance is hot. Wait until the water cools down

#### Proceed as follows to clean the pump:


1. Open the pump cover.



- 2. Place a suitable bowl below the drain pump access to collect the water that flows out.
- **3.** Open the chute downwards. Always keep a rag nearby to dry up any water spillages when removing the filter.



**4.** Turn the filter 180 degrees in anticlockwise direction to open it, without removing. Let the water flow out.




- 5. When the bowl is full of water, turn the filter back and empty the container.
- **6.** Repeat the steps 4 and 5 until the water stops to flow out.


7. Turn the filter anti-clockwise to remove it.




- 8. If it is necessary, remove fluff and objects from the filter recess.
- **9.** Make sure that the impeller of the pump can rotate. If it does not rotate, contact the Authorised Service Centre.




10. Clean the filter under the water tap.



 Put the filter back into the special guides by turning it clockwise. Make sure that you tighten the filter correctly to prevent leakages.



12. Close the pump cover.




When you drain the water with the emergency drain procedure, you must activate the drain system again:

- a. Put 2 litres of water in the main wash compartment of the detergent dispenser.
- **b.** Start the programme to drain the water.


## 16.10 Cleaning the inlet hose and the valve filter

It is recommended to clean both the filters of the inlet hose and valve occasionally to remove any deposit, collected over the time:


1. Remove the inlet hose from the tap and clean the filter.




2. Remove the inlet hose from the appliance by loosening the ring nut.



**3.** Clean the valve filter on the back of the appliance with a toothbrush.



 When you reconnect the hose to the back of the appliance, turn it left or right (not in vertical position) depending on the position of your water tap.



### 16.11 Emergency drain

If the appliance cannot drain the water, carry out the same procedure, described in 'Cleaning the drain pump' paragraph. If necessary, clean the pump.

When you drain the water with the emergency drain procedure, you must activate the drain system again:

- 1. Put 2 litres of water in the main wash compartment of the detergent dispenser.
- 2. Start the programme to drain the water.

## **17.** TROUBLESHOOTING

### / WARNING!

Refer to Safety chapters.

### 17.1 Alarm Codes and Possible failures

The appliance does not start or it stops during operation. First try to find a solution to the problem (refer to the tables).

### ⚠ WARNING!

Deactivate the appliance before carrying out any check.

### 16.12 Frost precautions

If the appliance is installed in an area where the temperature can reach the values around 0° C or drop below, remove the remaining water from the inlet hose and the drain pump.

- 1. Disconnect the mains plug from the mains socket.
- 2. Close the water tap.
- **3.** Put the two ends of the inlet hose in a container and let the water flow out of the hose.
- **4.** Empty the drain pump. Refer to the emergency drain procedure.
- 5. When the drain pump is empty, install the inlet hose again.

#### A WARNING!


Make sure that the temperature is higher than 0 °C before you use the appliance again.

The manufacturer is not responsible for damages caused by low temperatures.

With some problems, the display shows an alarm code and the Start/  $\mathsf{Pause} \bigcup I$  button may flash continuously:

 $(\mathbf{i})$ 

If the appliance is overloaded, remove some items from the drum and/or keep pressed the door while touching the Start/Pause button until the indicator **-0** stops flashing (see the picture below).



Problem	Possible solution
E ID The appliance does not fill with water properly.	<ul> <li>Make sure that the water tap is open.</li> <li>Make sure that the pressure of the water supply is not too low. For this information, contact your local water authority.</li> <li>Make sure that the water tap is not clogged.</li> <li>Make sure that the inlet hose has no kinks, damages or bends.</li> <li>Make sure that the connection of the water inlet hose is correct.</li> <li>Make sure that the filter of the inlet hose and the filter of the valve are not clogged. Refer to 'Care and cleaning'.</li> </ul>
E2D The appliance does not drain the water.	<ul> <li>Make sure that the sink spigot is not clogged.</li> <li>Make sure that the drain hose has no kinks or bends.</li> <li>Make sure that the drain filter is not clogged. Clean the filter, if necessary. Refer to "Care and cleaning".</li> <li>Make sure that the connection of the drain hose is correct.</li> <li>Set the drain programme if you set a programme without drain phase.</li> <li>Set the drain programme if you set an option which ends with water in the tub.</li> </ul>
E4D The appliance door is open or not closed correctly.	Make sure that the door is properly closed.
ES I Internal fail. No communica- tion between electronic ele- ments of the appliance.	<ul> <li>The programme was not finished properly or the appliance stopped too early. Switch the appliance off and on again.</li> <li>If the alarm code appears again, contact the Authorised Service Centre.</li> </ul>
EHD The mains supply is unsta- ble.	Wait until mains supply is stable.

If the display shows other alarm codes, deactivate and activate the appliance. If the problem continues, contact the Authorised Service Centre. In case of different problem with the appliance check the table below for possible solutions.

Problem	Possible solution
	<ul> <li>Make sure that the mains plug is connected to the mains socket.</li> <li>Make sure that the appliance door is closed.</li> <li>Make sure that there is no damaged fuse in the fuse box.</li> </ul>
The programme does not start.	<ul> <li>Make sure that the Start/Pause I has been touched.</li> <li>If the delay start is set, cancel the setting or wait for the end of countdown.</li> <li>Deactivate the Child Lock function if it is on.</li> <li>Check the position of the knob on the selected programme.</li> </ul>
The appliance fills with water and drains immediately.	Make sure that the drain hose is in the correct position. The hose may be positioned too low. Refer to "Installation instruction".
The spin phase does not op- erate or the washing cycle lasts longer than usual.	<ul> <li>Set the spin programme.</li> <li>Make sure that the drain filter is not clogged. Clean the filter, if necessary. Refer to "Care and cleaning".</li> <li>Adjust manually the items in the tub and start the spin phase again. This problem may be caused by balance problems.</li> </ul>
There is water on the floor.	<ul> <li>Make sure that the couplings of the water hoses are tight and there is not water leakages.</li> <li>Make sure that the water inlet hose and the drain hose have no damages.</li> <li>Make sure you use the correct detergent and the correct quantity of it.</li> </ul>
You cannot open the appli- ance door.	<ul> <li>Make sure that a washing programme that ends with water in tub, has not been selected.</li> <li>Make sure that the washing programme is finished.</li> <li>Set the drain or the spin programme if there is water in the drum.</li> <li>Make sure that the appliance receives electrical power.</li> <li>This problem may be caused by a failure of the appliance. Contact the Authorised Service Centre. If you need to open the door, please read carefully "Emergency door opening".</li> </ul>
The appliance makes an un- usual noise and vibrates.	<ul> <li>Make sure the levelling of the appliance is correct. Refer to "Installation instruction".</li> <li>Make sure that the packaging and/or the transit bolts are removed. Refer to "Installation instruction".</li> <li>Add more laundry in the drum. The load may be too small.</li> </ul>
The programme duration in- creases or decreases during programme execution.	<ul> <li>The SensiCare System is able to adjust the programme duration according to the type and the laundry load size. Refer to "The SensiCare System load de- tection" in "Daily Use" chapter.</li> </ul>
The washing results are not satisfactory.	<ul> <li>Increase the detergent quantity or use a different detergent.</li> <li>Use special products to remove the stubborn stains before you wash the laundry.</li> <li>Make sure that you set the correct temperature.</li> <li>Decrease the laundry load.</li> </ul>

Problem	Possible solution
Too much foam in the drum during the washing cycle.	Reduce the quantity of detergent or the number of tablets or single-dose deter- gents.
The appliance does not dry or does not dry correctly.	<ul> <li>Turn the water tap on.</li> <li>Make sure the drain filter is not clogged.</li> <li>Reduce the laundry load.</li> <li>Make sure you have set the correct cycle. if necessary, set again a short drying time.</li> </ul>
The laundry is full of different colours fluff.	<ul> <li>The fabrics washed in the previous cycle released fluff of a different colour:</li> <li>The drying phase helps to eliminate some fluff.</li> <li>Clean the clothes with a fluff remover.</li> <li>In case of an excessive amount of fluff in the drum refer to "Fluff in the fabrics" paragraph for more details.</li> </ul>

After the check, activate the appliance. The programme continues from the point of interruption.

If the problem occurs again, contact the Authorised Service Centre. The necessary data for the service centre are on the rating plate.

## 17.2 Emergency door opening

In case of power failure or functioning failure the appliance door remains locked. The washing programme continues when the power is restored. If the door remains locked in case of failure, it is possible to open it using the emergency unlock function.

Before opening the door:

### ⚠̀ CAUTION!

Risk of burns! Make sure that the water temperature is not too high and the laundry is not hot. If necessary, wait until they cool down.


### 

Risk of injury! Make sure that the drum is not rotating. If necessary, wait until the drum stops rotating.

### $(\mathbf{i})$

Make sure that the water level inside the drum is not too high. If necessary, proceed with an emergency drain (refer to «Emergency drain» in «Care and cleaning» chapter). To open the door, proceed as follows:

- 1. Press the On/Off button to switch the appliance off.
- 2. Disconnect the mains plug from the mains socket.
- 3. Open the filter flap.
- 4. Pull the emergency unlock trigger downward once. Pull it downward once again, keep it tensed and, in the meanwhile, open the appliance door.



- 5. Take out the laundry and then close the appliance door.
- 6. Close the filter flap.

## **18. CONSUMPTION VALUES**

### **18.1 Introduction**

## $(\mathbf{i})$

The QR code on the energy label supplied with the appliance provides a web link to the information related to the performance of the appliance in the EU EPREL database. Keep the energy label for reference together with the user manual and all other documents provided with this appliance.

It is also possible to find the same information in EPREL using the link **https://eprel.ec.europa.eu** and the model name and product number that you find on the rating plate of the appliance. Refer to 'Product description' chapter for the position of the rating plate.

### 18.2 Legend

kg	Laundry load.	hh:mm	Programme duration.		
kWh	Energy consumption.	°C	Temperature in the laundry.		
Litres	Water consumption.	rpm	Spin speed.		
%	Remaining moisture at the end of the cycle. The higher is the spin speed, the higher is the noise and the lower is the remaining moisture at the end of washing cycle.				

## $(\mathbf{i})$

Values and programme duration may differ depending on different conditions (e.g. room temperature, water temperature and pressure, load size and type of laundry, supply voltage) and also if you change the default setting of a programme.

#### 18.3 According to Commission Regulation Eu 2019/2023

Eco 40-60 pro- gramme	kg	kWh	Litres	hh:mm	%	°C	rpm <sup>1)</sup>
Full load	9.0	0.790	63.0	03:48	53.0	37.0	1400
Half load	4.5	0.495	44.0	02:53	53.0	30.0	1400
Quarter load	2.5	0.240	31.0	02:50	54.0	24.0	1400

1) Maximum spin speed.

Washing only

### Wash and dry cycle

Eco 40-60 pro- gramme and Cup- board dry level	kg	kWh	Litres	hh:mm	%	°C	rpm <sup>1)</sup>
Full load	5.0	3.255	78.0	06:05	0.00	35.0	1400
Half load	2.5	1.750	44.0	04:20	0.00	32.0	1400

1) Maximum spin speed.

### Power consumption in different modes

Off (W)	Stand-by (W) Delay start			
0.50	0.50	4.00		
T: 1 0 10 1 1 1 1 1 1 1				

Time to Off/Standby mode is 15 minutes maximum.

### 18.4 Common programmes -Washing only

## $(\mathbf{i})$

These values are indicative only.

Programme	kg	kWh	Litres	hh:mm	%	°C	rpm <sup>1)</sup>
Cottons <b>2)</b> 90°C	9.0	2.800	100.0	03:30	52.0	85.0	1400
Cottons 60°C	9.0	1.950	95.0	03:10	52.0	55.0	1400
Cottons <b>3)</b> 20°C	9.0	0.350	95.0	03:00	52.0	20.0	1400
Synthetics 40°C	3.0	0.600	60.0	02:10	35.0	40.0	1200
Delicates <b>4)</b> 30°C	2.0	0.350	55.0	01:10	35.0	30.0	1200
Wool 30°C	1.5	0.250	50.0	01:10	30.0	30.0	1200

1) Maximum spin speed.

2) Suitable for washing heavily soiled textiles.

3) Suitable for washing lightly soiled cottons, synthetic and mixed fabrics.

4) It also performs as quick washing cycle for lightly soiled laundry.

## 18.5 Common programmes - Wash and dry

### $(\mathbf{i})$

These values are indicative only.

Programme	kg	kWh	Litres	hh:mm	%	°C	rpm <sup>1)</sup>
Synthetics 40°C	3.0	1.800	70.0	03:25	1.00	40.0	1200

1) Maximum spin speed.

## **19. ENVIRONMENTAL CONCERNS**

Recycle materials with the symbol  $\overleftrightarrow$ . Put the packaging in relevant containers to recycle it. Help protect the environment and human health by recycling waste of electrical and electronic appliances. Do not dispose of

appliances marked with the symbol A with the household waste. Return the product to your local recycling facility or contact your municipal office.

.....

.....

## electrolux.com



CE

157083320-A-102024