



#### Delicate glasses are in good hands

Glasses need a little extra tender loving care, especially when getting washed. Good thing the upper basket in the 700 GlassCare dishwasher has SoftGrips that securely yet gently hold your glasses. While SoftSpikes make sure they don't get scratched, or worse break.

### Product Benefits & Features

#### Delicate glasses protected with SoftGrips and SoftSpikes

With SoftGrips and SoftSpikes you no longer need to spend time handwashing delicate glasses. The soft material gently holds glasses securely in place and protects them from cracks and breakage.



#### All your cutlery, washed in one go with MaxiFlex

The MaxiFlex drawer is designed to fit cutlery and utensils of different shapes and sizes. Whether large or awkwardly shaped, the customisable dividers and deep drawer mean everything can be loaded with ease.



#### Sustainable dishwashing made easy

Sustainable choices made easy. Use the QuickSelect touchscreen slider to select your preferred cycle time and the Ecometer displays the most sustainable program to save energy and water through intuitive green bars.

#### SatelliteClean®. Complete cleaning. Without using extra water

Dishes come out spotless with SatelliteClean®—it performs up to 3x better than the standard dishwasher. Thanks to the double-rotating arm that continuously changes the angle of the spray, even bulky items are deeply cleaned.

#### Water touches every corner, with the Dual Spray Arms

Every glass, dish and plate is covered by the dishwasher's two rotating spray arms. The sprinklers make sure water gets into every corner, so your dishes come out sparkling. On both the upper and lower basket.

- Auto Off function
- Touch control for programs and functions selection
- Drying system: AirDry Technology
- Water sensor detects the level of dirt and adjusts water consumption
- Dual safety - Floating switch
- Indications for salt and rinse aid
- FlexiSpray Satellite spray arm
- Ceiling sprayarm
- Height adjustable upper basket, even when fully loaded
- Upper basket with 2 Soft Spikes, 6 wine glass soft grips, Foldable cup shelves, Plastic handle
- Lower basket with 2 foldable tines, Plastic handle
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
- Delay Start

**Product Specification**

Installation	FI	Drying performance index 3 digitE20	1.061
Rated capacity psE20	10	Weighted average energy consumption / 100 cycles, kWh (E20)	67
Energy efficiency class, legal (E20)	D	Water consumption / cycle IE20	9.9
Airborne acoustical noise emissions, dBA re 1 pW	44	Hinges	Sliding
Door colour	None	Connected load, W	1950
XXL-Tub	No	Cord length, m	15
Dimensions_Dishwasher_FSBU_DK	820-900x450x550	Outlet hose length, cm	150
Number of programs	8	Required fuse (A)	10
Number of temperatures	3	Inlet hose length, cm	150
Dimensions HxWxD in mm	818x446x550	Inlet hose type	Aqua control
Airborne acoustical noise emission class	B	Anti-flood device	Floating switch
Depth open door	1200	Water supply	Cold or Hot
Nordic_DW_CutleryType	Cutlery drawer	Upper spray arm	Dual spray arms
Nordic_DW_QuickSelect	Level 3	Lower spray arm	Satellite spray arm
Nordic_DW_SoftGrips	6 SoftGrip holders	Options	ExtraHygiene, GlassCare, XtraPower
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
Nordic_DW_GlassCare2G	No	Installation in height	None
Beam on floor	Red&Green	Nordic_DW_DoorPanelHeight	645-776
Interior light	No	Nordic_DW_DoorPanelWeight	2-6
Nordic_DW_DoorFitKit	No	Indicator program	LED
Cleaning performance index3 digitE20	1.121	Installation type	Built_In
		Net weight, kg	34
		Bar code	7332543738397

