

EEG68520W



Delicate glasses are in good hands

Glasses need a little extra tender loving care, especially when getting washed. Good thing the upper basket in the 700 GlassCare dishwasher has SoftGrips that securely yet gently hold your glasses. While SoftSpikes make sure they don't get scratched, or worse break.

Product Benefits & Features



Delicate glasses protected with SoftGrips and SoftSpikes

With SoftGrips and SoftSpikes you no longer need to spend time handwashing delicate glasses. The soft material gently holds glasses securely in place and protects them from cracks and breakage.



All your cutlery, washed in one go with MaxiFlex The MaxiFlex drawer is designed to fit cutlery and utensils of different shapes and sizes. Whether large or awkwardly shaped, the customisable dividers and deep drawer mean everything can be loaded with ease.

Sustainable dishwashing made easy

Sustainable choices made easy. Use the QuickSelect touchscreen slider to select your preferred cycle time and the Ecometer displays the most sustainable program to save energy and water through intuitive green bars.



QuickSelect with Wi-Fi: Connected dishwasher control via your smart device

Our connected QuickSelect dishwashers enable smart, sustainable dishwashing. Get guidance on the right program for your load and select when to run the dishwasher to reduce energy costs. The app summarises usage and gives sustainability feedback.

SatelliteClean®. Complete cleaning. Without using extra water

Dishes come out spotless with SatelliteClean®—it performs up to 3x better than the standard dishwasher. Thanks to the double-rotating arm that continuously changes the angle of the spray, even bulky items are deeply cleaned.

- XXL tub
- Auto Off function
- Touch control for programs and functions selection
- · Internal light for optimal visibility in the dishwasher
- Drying system: AirDry Technology
- Water sensor detects the level of dirt and adjusts water consumption
- · Dual safety Floating switch
- · Indications for salt and rinse aid
- FlexiSpray Satellite spray arm
- Ceiling sprayarm
- · Height adjustable upper basket, even when fully loaded
- Upper basket with 6 wine glass soft grips, 2 Foldable racks, 2 Foldable wires for glasses, 2 Soft Spikes, Foldable cup shelves, Plastic handle Electrolux
- Lower basket with 4 foldable tines, Plastic handle
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, Eco, Machine Care, Quick 30 Minutes, Rinse & Hold
- Delay Start



EEG68520W

Product Specification			
Installation	FI	Cleaning performance index3 digitE20	1.121
Rated capacity psE20	14	Drying performance index 3 digitE20	1.061
Energy efficiency class, legal (E20)	В	Weighted average energy	64
Airborne acoustical noise emissions, dBA re 1 pW	42	consumption / 100 cycles, kWh (E20) Water consumption / cycle IE20	9.9
Door colour	None	Hinges	Sliding
XXL-Tub	Yes	Connected load, W	1550-2200
Dimensions_Dishwasher_FSBU_DK	820-900x600x560	Cord length, m	16
Number of programs	8	Outlet hose length, cm	180
Number of temperatures	4	Required fuse (A)	10
Dimensions HxWxD in mm	818x596x560	Inlet hose length, cm	180
Airborne acoustical noise emission class	В	Inlet hose type	Aqua control
Depth open door	1230	Anti-flood device	Floating switch
Connectivity	Yes	Water supply	Cold or Hot
•		Upper spray arm	Standard spray arm
Nordic_DW_CutleryType	Cutlery drawer Level 3	Lower spray arm	Satellite spray arm
Nordic_DW_QuickSelect	==	Options	ExtraHygiene, GlassCare, XtraPower
Nordic_DW_SoftGrips Nordic_DW_SoftSpikes	6 SoftGrip holders 2 SoftSpikes holders	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
Nordic_DW_GlassCare2G	No No	Installation in height	None
Beam on floor	Red&Green	Nordic_DW_DoorPanelHeight	670-825
Interior light	Yes	Nordic_DW_DoorPanelWeight	15-10
Nordic DW DoorFitKit	No	Indicator program	LED Display
		Installation type	Built_In
		Net weight, kg	37.28

