

Powerful cleaning, easy to load

A multi-angled spray arm gives the 600 series extra spray coverage. Easy to load, with spacious baskets and foldable rows. No-fuss, time-based cycle selection.

Product Benefits & Features

Easy, time-based program selection



With TimeSet you don't have to figure out what program to use. Just decide how soon you want your dishes to be ready, set the cycle length and press start.

Double-rotating spray arm cleans from all directions



360Clean spray arm thoroughly cleans your dishes with powerful, double-rotating spray coverage. Even closely placed or larger dishes receive deep cleaning no matter where they are loaded. And all without using any more water or energy.

Versatile drawer with knife holder fits cutlery and utensils



The FlexiMax drawer with knife holder is designed to fit cutlery and many different shapes and sizes of utensils. The customisable dividers and deep drawer mean large or awkwardly shaped items can be loaded with ease.

Effective cleaning and hygienic care



ExtraHygiene removes more than 99.9999% of bacteria and viruses*. The cleaning phase heats up to 69°C for a minimum of 10 minutes to remove microorganisms. This sanitizes your dishes, for spotless results with hygienic care.

*Tested for Micrococcus luteus and MS2 bacteriophage in external test performed by Swissatest Testmaterialien AG in 2021 (Test Report No. 20212029).

Uses fresh air to finish drying



AirDry uses fresh air to finish drying the dishes. This makes the drying performance up to 3x better compared to a closed-door system. The door automatically opens towards the end of the cycle to let in fresh air.

- Delay Start
- Indications for salt and rinse aid
- AirDry
- Auto Off function
- Upper basket with 2 rows of fixed tines, 2 Soft Spikes, Foldable cup shelves, plastic handle Electrolux
- Lower basket with 4 rear foldable tines, Low round rack frame, Plastic handle
- Options: ExtraHygiene, GlassCare, PowerBoost
- Dishwasher programmes: 120 Minutes, 60 Minutes, 90 Minutes, AUTOClean, ECO, MachineClean, QuickClean, QuickRinse

Product Specification

Installation	FSBU	Lower basket, Level 1, max	270
Airborne acoustical noise emissions, dBA re 1 pW	42	Lower basket, Level 2, max	315
Door colour	White	Upper spray arm	Standard spray arm
Dimensions_Dishwasher_FSBU_DK	820-880x600x570	Lower spray arm	360Clean
Number of programs	8	Options	ExtraHygiene, GlassCare, PowerBoost
Number of temperatures	3	Options available only through the App	None
Dimensions HxWxD in mm	818x596x570	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 6cm)
Depth open door	1140	Installation in height	None
Nordic_DW_CutleryType	Cutlery drawer	Indicator program	Display 3 digits
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Installation type	Free_Standing
Nordic_DW_GlassCare2G	No	Net weight, kg	36.59
Interior light	No	Bar code	7333394171982
Nordic_DW_DoorFitKit	No	Product Number Code	911 582 114
Hinges	Normal		
Connected load, W	1950		
Cord length, m	1.5		
Outlet hose length, cm	150		
Required fuse (A)	10		
Inlet hose length, cm	150		
Inlet hose type	Aqua control		
Anti-flood device	Floating switch		
Water supply	Cold or Hot		
Upper basket, Level 1, max	190		
Upper basket, Level 2, max	140		