


Powerful cleaning with spacious, flexible baskets

The 800 series delivers the cleaning power to completely remove baked-on or dried food residues. Flexible, easy-gliding baskets have foldable rows, plus holders to secure glasses and Eco-program uses as little as 8.4 litres of water.

Product Benefits & Features

Fully loaded lower basket rises 25 cm on reinforced hinges.

ComfortLift®, no more bending, just easy loading. Tested to lift 30 000 times*. Raises the lower basket to the upper basket's level for faster, easier loading and unloading.


Double-rotating spray disk cleans from all directions

Complete removal of stubborn food-residues in only 90 min. Tested and verified*. A spray arm with two nozzles, one circular and one straight, efficiently delivers water from multiple angles. The result is sparkling dishes every time.

*Based on internal testing of the ComfortLift® mechanism subjected to 30,000 rack operations (extraction, lift and closure) and loaded according to IEC 60436:2025 tableware.

*Based on an independent test by third-party German institute using detergent tablets and 90 min cycle on casserole with lasagna residues


Spacious, easy-to-load baskets with cutlery drawer

Redesigned, smooth-gliding FlexiMax Baskets have two folding rows to fit large or oddly shaped crockery. Anti-slip rubber spikes keep glassware and delicate items from colliding. Cutlery drawer even fits whisks and ladles.


Just select cycle time. No need to choose between programmes

An easier way to use your dishwasher. QuickSelect Connect display shows how energy use changes, depending on the cycle length. Move the slider to choose time, and see the energy graph change. Loading, program, and maintenance tips in the app.


1 cycle, 2 zones. Intense on pots and pans, gentle on glassware

Two cleaning zones in the same cycle, without changing water or energy use. Activate DualZone to get tailored cleaning, with more water pressure on pots and pans in the lower basket and reduced pressure on delicate items in the upper basket.

- LightOnFloor
- Touch control for programs and functions selection
- Delay Start
- Indications for salt and rinse aid
- AirDry
- WaterSmart
- Auto Off function
- Upper basket with 2 front folding tines for glasses, 2 Soft Spikes, Foldable cup shelves, Plastic handle ELUX
- Lower basket with 4 rear foldable tines with tine caps, Stainless steel handle, Tall flat rack frame ComfortLift
- Options: DualZone, ExtraHygiene, GlassCare
- Dishwasher programmes: 120 Minutes, 60 Minutes, 90 Minutes, AUTOClean, ECO, MachineClean, QuickClean, QuickRinse

Product Specification			
Installation	FI	Drying performance index 3 digitE20	1.061
Rated capacity psE20	14	Weighted average energy consumption / 100 cycles, kWh (E20)	75
Energy efficiency class, legal (E20)	C	Water consumption / cycle IE20	8.4
Airborne acoustical noise emissions, dBA re 1 pW	44	Hinges	Sliding up to 12kg
Door colour	None	Connected load, W	1550-2200
XXL-Tub	No	Cord length, m	1.6
Dimensions_Dishwasher_FSBU_DK	820-900x600x550	Outlet hose length, cm	180
Number of programs	8	Required fuse (A)	10
Number of temperatures	3	Inlet hose length, cm	180
Dimensions HxWxD in mm	815x596x550	Inlet hose type	Aqua control
Airborne acoustical noise emission class	B	Anti-flood device	Floating switch
Depth open door	1235	Water supply	Cold or Hot
Connectivity	Yes	Upper basket, Level 1, max	190
Nordic_DW_CutleryType	Cutlery drawer	Upper basket, Level 2, max	160
Nordic_DW_QuickSelect	Level 3	Lower basket, Level 1, max	280
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Lower basket, Level 2, max	310
Nordic_DW_GlassCare2G	No	Upper spray arm	Standard spray arm
Indicator on Floor	LightOnFloor	Lower spray arm	360Clean Pro
Interior light	No	Options	DualZone, ExtraHygiene, GlassCare
Nordic_DW_DoorFitKit	No	Options available only through the App	None
Cleaning performance index3 digitE20	1.121	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
		Installation in height	None

