



Natural drying with fresh air

Our 300 AirDry Dishwasher finishes each cycle with a breath of fresh air, performing 3x better than closed-door systems. The door opens automatically during the drying phase using fresh air to get plates and cutlery completely dry.

Product Benefits & Features



3x better drying with AirDry

The new AirDry technology uses natural airflow to finish drying, for up to 3x better performance compared to closed-door systems. The door opens 10 cm towards the end of the cycle, letting air circulate for superb drying results.

QuickSelect: Just slide to the time you need

Use the QuickSelect touchscreen slider to select your preferred cycle time. It displays the energy and water levels per program through intuitive green bars.

Water touches every corner, with the Dual Spray Arms

Every glass, dish and plate is covered by the dishwasher's two rotating spray arms. The sprinklers make sure water gets into every corner, so your dishes come out sparkling. On both the upper and lower basket.



Silent feedback, Beam on Floor

The Beam on Floor illuminated feedback system keeps your kitchen quiet. Instead of a loud beep that can be drowned out by background noise, our dishwasher clearly tells you its status by projecting a dot on the floor. Red when it's running, and green when it's complete.



QuickLift - change the basket height even when fully loaded

Whether loading or removing dishes do it comfortably with the QuickLift basket. Even when the upper basket is fully flooded, the QuickLift system allows you to quickly raise and lower your rack to fit dishes and kitchen tools of different shapes and sizes.

- Beam on Floor red and green light
- Touch control for programs and functions selection
- Delay Start
- Indications for salt and rinse aid
- AirDry
- Auto Off function
- Upper basket with 2 Soft Spikes, Foldable cup shelves, Plastic handle
- Lower basket with 2 foldable tines, Plastic handle
- Options: GlassCare, XtraPower
- Dishwasher programmes: 160 Minutes, 60 Minutes, 90 Minutes, AUTO Sense, ECO, Machine care, Quick 30 Minutes, Rinse & Hold

Product Specification			
Installation	FI	Weighted average energy consumption / 100 cycles, kWh (E20)	59
Rated capacity psE20	10	Water consumption / cycle IE20	9.9
Energy efficiency class, legal (E20)	C	Hinges	Sliding
Airborne acoustical noise emissions, dBA re 1 pW	44	Connected load, W	1550-2200
Door colour	None	Cord length, m	1.5
Dimensions_Dishwasher_FSBU_DK	820-900x450x550	Outlet hose length, cm	150
Number of programs	8	Required fuse (A)	10
Number of temperatures	3	Inlet hose length, cm	150
Dimensions HxWxD in mm	818x446x550	Inlet hose type	Aqua control
Airborne acoustical noise emission class	B	Anti-flood device	Floating switch
Depth open door	1200	Water supply	Cold or Hot
Nordic_DW_CutleryType	Cutlery drawer	Upper basket, Level 1, max	120
Nordic_DW_QuickSelect	Level 2	Upper basket, Level 2, max	160
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Lower basket, Level 1, max	270
Nordic_DW_GlassCare2G	No	Lower basket, Level 2, max	310
Indicator on Floor	Red&Green	Upper spray arm	Dual spray arms
Interior light	No	Lower spray arm	Standard
Nordic_DW_DoorFitKit	No	Options	GlassCare, XtraPower
Cleaning performance index3 digitE20	1.121	Options available only through the App	None
Drying performance index 3 digitE20	1.061	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
		Installation in height	None
		Nordic_DW_DoorPanelHeight	645-776
		Nordic_DW_DoorPanelWeight	2-6