



Powerful cleaning, easy to load baskets


A multi-angled spray arm gives the 600 series extra spray coverage. Easy to load, with spacious baskets and foldable rows. No-fuss, time-based cycle selection.

Product Benefits & Features



Just select cycle time. No need to choose between programmes

An easier way to use your dishwasher. QuickSelect display shows how energy use changes, depending on the cycle length. Move the slider to choose time, and see the energy graph change.



Double-rotating spray arm cleans from all directions

360Clean spray arm thoroughly cleans your dishes with powerful, double-rotating spray coverage. Even closely placed or larger dishes receive deep cleaning no matter where they are loaded. And all without using any more water or energy.



Versatile drawer with knife holder fits cutlery and utensils

The FlexiMax drawer with knife holder is designed to fit cutlery and many different shapes and sizes of utensils. The customisable dividers and deep drawer mean large or awkwardly shaped items can be loaded with ease.



Anti-slip, rubber spikes for secure glass care

Rubber, anti-slip SoftSpikes® protect your glassware. They gently hold items in place to reduce the risk of chips and scratches due to collisions.



A light shines onto the floor to show the dishwasher is running

LightOnFloor® shines a white light onto the floor whilst a cycle is under way. The light turns off when the cycle is complete and the dishes are ready to be unloaded.

- LightOnFloor
- Touch control for programs and functions selection
- Delay Start
- Indications for salt and rinse aid
- AirDry
- Auto Off function
- Upper basket with 2 rows of fixed tines, 2 Soft Spikes, Foldable cup shelves, plastic handle Electrolux
- Lower basket with Low round rack frame, 2 rear foldable tines, plastic handle
- Options: GlassCare, PowerBoost
- Dishwasher programmes: 120 Minutes, 60 Minutes, 90 Minutes, AUTOClean, ECO, MachineClean, QuickClean, QuickRinse

Product Specification

Installation	FI	Weighted average energy consumption / 100 cycles, kWh (E20)	75
Rated capacity E20	14	Water consumption / cycle IE20	10.5
Energy efficiency class, legal (E20)	C	Hinges	Sliding up to 10kg
Airborne acoustical noise emissions, dBA re 1 pW	44	Connected load, W	1950
Door colour	None	Cord length, m	1.5
Dimensions_Dishwasher_FSBU_DK	820-900x600x550	Outlet hose length, cm	150
Number of programs	8	Required fuse (A)	10
Number of temperatures	3	Inlet hose length, cm	150
Dimensions HxWxD in mm	818x596x550	Inlet hose type	Aqua control
Airborne acoustical noise emission class	B	Anti-flood device	Floating switch
Depth open door	1200	Water supply	Cold or Hot
Nordic_DW_CutleryType	Cutlery drawer	Upper basket, Level 1, max	190
Nordic_DW_QuickSelect	Level 2	Upper basket, Level 2, max	140
Nordic_DW_SoftSpikes	2 SoftSpikes holders	Lower basket, Level 1, max	270
Nordic_DW_GlassCare2G	No	Lower basket, Level 2, max	315
Indicator on Floor	LightOnFloor	Upper spray arm	Standard spray arm
Interior light	No	Lower spray arm	360Clean
Nordic_DW_DoorFitKit	No	Options	GlassCare, PowerBoost
Cleaning performance index3 digitE20	1.121	Options available only through the App	None
Drying performance index 3 digitE20	1.061	Feet/Wheels	2 adj feet + 1 front adj rear foot (adj 0 to 8cm)
		Installation in height	None
		Nordic_DW_DoorPanelHeight	645-776
		Nordic_DW_DoorPanelWeight	2-10

